



Wheel Lift System



Operating Instructions & Parts Manual

Model Number
HW93693

Capacity
10 Tons (per pair)



**Made in the
U.S.A.**



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid injury or death.

READ THIS MANUAL CAREFULLY AND RETAIN FOR YOUR RECORDS
U.S. Patent No. D357,106 & 5,484,134

SFA Companies
10939 N. Pomona Ave. Kansas City, MO 64153
customerservices@heinwerner-automotive.com

Read this manual and follow all the Safety Rules and Operating Instructions before using this product

Table of Contents

Receiving Inspection	1
Introduction	1
Owner and / or Operator Responsibilities	1
Specifications	1
Component Identification	2
HW93693	2
Safety Instructions	3
Optional Adapters	4
Installing the WL-Adapters	4
Using the WL-Adapters	4
Operating Instructions	4
Preparing the Lifts and Vehicle	5
Raising A Vehicle	5
Pinning the Lifts as Stands	6
Lowering a Vehicle to the Ground	6
Using the Wheel Lifts with Support Stands	7
Transferring a Load to Support Stands	7
Removing Support Stands	8
Maintenance Instructions	9
Lubrication	9
Lift Table Adjustment	9
Air Control Unit Cleaning Instructions	10
Structural Inspection	10
Air Hose Inspection	11
Troubleshooting	12
Notes	13

Receiving Inspection

Before attempting to operate this system, thoroughly read and understand this manual. Inspect the jacks immediately upon delivery. If shipping damage is evident, inform the delivering carrier immediately and contact customer service at the address and numbers on the back cover of this manual.

Owner and / or Operator Responsibilities

The owner and / or user must have an understanding of the manufacturer's operating instructions and warnings before using this system. The use of portable lifting devices is subject to certain hazards that cannot be avoided by mechanical means, but only by the exercise of intelligence, care, and common sense. Personnel involved in the use and operation of equipment shall be careful, competent, trained, and qualified in the safe operation of the equipment and its proper use when servicing motor vehicles and their components. Examples of hazards are dropping, tipping, or slipping of vehicles or their components caused primarily by improperly securing loads, overloading, off-centered loads, use on other than hard level surfaces, and using equipment for a purpose for which it was not designed. Warning information should be emphasized and understood.

The owner / manager must make this manual available to all personnel using this jack at your direction. They must read and understand the contents of this manual. If the operator is not fluent in English, the manufacturer's instructions and warnings shall be read to and discussed with the operator in the operator's native language by the purchaser / owner, making sure that the operator comprehends its contents and observes the proper procedures for use of this jack.

Owner and / or user must study and maintain for future reference the manufacturer's instructions. Owner and / or user are responsible for keeping all warning labels and instruction manuals legible and intact. Replacement labels and literature are available from the manufacturer.

Specifications

Model Number	HW93693
Maximum Capacity, each lift	10,000 lbs./4,540 kg.
Maximum Capacity, system	20,000 lbs./9,075 kg.
Maximum Air Pressure	160 psi
Minimum Wheel Dia. w/o Adapters	19"
Minimum Wheel Dia. with Adapters	16"
Maximum Tire to Fender Clearance	8"
System Weight	1,030 lbs.
Weight per Lift	513 lbs.
Adapter Weight	22 lbs.
Width	41 ⁹ / ₁₆ "
Depth	39 ¹ / ₂ "
Height (lowered)	53 ¹ / ₄ "
Height (raised)	77 ¹ / ₄ "

Component Identification HW93693




Figure 1



Safety Instructions

To avoid serious injury or death, read this manual carefully before operating this system. Call customer service at the address and numbers on the back cover of this manual if you have any questions.

Failure to understand and obey safety instructions may result in unsafe or improper use of this product.

WARNING

1. Maximum capacity for the HW93693 is 10,000 lbs./4,540 kg. per wheel lift. Never use the Wheel Lift System to raise or support more than maximum capacity per lift. Never use a lift as a stand to support more than maximum capacity per lift.
2. No alterations shall be made to this product.
3. Use the Wheel Lift System only on hard, level surfaces capable of sustaining the load.
4. The Wheel Lift System is designed to lift over-the-road vehicles with rims of at least 19 inches in diameter (16 inches in diameter if HW optional adapters are used). *NEVER* use the Wheel Lift System on vehicles with rims less than 19 inches in diameter (16 inches if adapters are used).
5. Use the Wheel Lifts only in pairs, on the opposite ends of the same axle.
6. *NEVER* use the Wheel Lift System to raise a vehicle by the frame or structural member. The lift is designed to be used only beneath the vehicle tires.
7. *NEVER* raise one end of a vehicle if the opposite end is supported by stands.
8. To prevent tipping, never raise or lower just one side of a vehicle.



9. *NEVER* lift an entire vehicle with the Wheel Lift System.
10. Do not allow any part of your body under the vehicle until both the Wheel Lifts are pinned as stands.
11. *NEVER* use the Wheel Lift System in conjunction with any other equipment used to raise a vehicle.
12. *NEVER* use blocks, adapters not supplied by manufacturer, or cribbing devices with this Wheel Lift System.
13. *NEVER* use the Wheel Lift System as a wheel dolly for the removal of tires.
14. *NEVER* allow the Wheel Lift System to be used unless all warning labels and instructional decals are in place and legible.
15. *NEVER* use this jack to lower a vehicle if the vehicle was raised using another lifting device or devices. You should lower the vehicle with the same equipment that was used to properly raise it (read and follow the warnings and instructions for this other equipment).

Failure to understand and obey this warning may result in personal injury or death.

Optional Adapters



WARNING

To prevent serious injury or death from a falling vehicle, use WL-Adapters only for vehicles with rims between 16" and 19" in diameter.



CAUTION

Install the WL-Adapters with both hooks in the holes of the lift pad. Proper installation is shown in figure 2.

Make sure the wheel rims on the vehicle to be raised are a minimum of 19" in diameter, unless you are using HW WL-Adapters with the Wheel Lift System. With the adapters, properly positioned on the lift pads, vehicles with wheel rims of 16" can be safely raised. For rims of 16-19 inches in diameter, install the WL-Adapters as follows:

Installing the WL-Adapters

To install the WL-Adapters, insert the adapter hooks on each WL-Adapter into the top two holes on each of the four lift pads. See top view and front view figures below.





Figure 2
Installing WL-Adapters.

Using the WL-Adapters

1. Use the WL-Adapters only on vehicles with rims of 16 inches - 19 inches in diameter. Follow normal operating instructions to use the Wheel Lift System with WL-Adapters installed.

Figure 3
Lift table tube identification



Operating Instructions

Preparing the Lifts and Vehicle

WARNING

To prevent serious injury or death from a falling vehicle, make sure the vehicle's rims are at least 19 inches in diameter (or 16" and 19" if WL-Adapters are used). Make sure the tires are properly inflated, to maintain necessary tire diameter. Make sure weight on the vehicle axle does not exceed 30,000 lbs.

WARNING

To prevent serious injury or death from a falling vehicle, make sure that the hoses avoid all pinch points and that they do not pass under the base of a lift. The base lowers slightly as the vehicle is raised.

1. Before proceeding, review the Safety Instructions section of this manual.
2. Position the vehicle on a hard, level surface and set the parking brake.
3. Check that the tires on the vehicle are properly inflated, to maintain necessary tire diameter.
4. Position the Wheel Lifts so the lift pads are cradling the tires at opposite ends of the same axle.
5. Push the lift pad under the tire until the lift table tube contacts the tire (see Figure 3 for identification).
6. Release the vehicle's parking or air brake and place the transmission in neutral.
7. Uncoil the air hoses from both lifts and route them for connecting to the air control unit, at either the front or the rear of the vehicle.
8. Position yourself at the front or rear of the vehicle so both lifts are visible. Face the vehicle and hold the air control unit with the air control levers pointing toward the vehicle and the quick couplers on the underside of the air control unit. (See figure 4 for orientation).
9. Connect the air hose from the lift on your right to the right side of the air control unit. Connect the air hose from the lift on your left to the left side of the air control unit (see Figure 4 for connections).
10. Connect the air supply (145 psi max) to the air inlet port of the air control unit (see Figure 4 for connection).




Figure 4
Move lever UP to raise lift, DOWN to lower. Operate BOTH levers SIMULTANEOUSLY to prevent vehicle tipping.

Raising A Vehicle

WARNING

To prevent serious injury or death from a falling vehicle, operate *both* air control levers *at the same time* and keep the vehicle level as it is raised or lowered.

WARNING

To prevent serious injury or death from a falling vehicle, operate *both* air control levers *at the same time* and keep the vehicle level as it is raised or lowered.

Raising A Vehicle (continued)

1. Raise the vehicle by lifting up on both the air control levers at the same time. Be sure to operate the air control levers so the vehicle stays level at all times as it is raised or lowered.
2. Raise the vehicle until it is 2"- 4" above the desired working height (the vehicle will lower by that amount as the downstop lugs engage). Visually confirm that the downstop pawls will engage downstop lugs at the same height on each lift. If they will not engage downstop lugs at the same height, carefully adjust vehicle level until the lifts are at the same height.
3. See figure 5 and 6 for downstop pawl and lug identification.




Figure 5
Downstop lug identification

Pinning the Lifts as Stands

1. With the vehicle 2"-4" above the final working height, carefully lower the lifts by pushing both the air control levers down at the same time until the downstop pawls engage the closest downstop lugs.
2. Visually confirm that the downstop pawls are securely engaged on the downstop lugs of each lift and the raised axle is level (see Figure 6).
3. On both lifts, remove the load retention pin from its holder and insert it through the oblong hole in the lift stop bar and fully into the corresponding hole in the downstop lug (see Figure 7) to pin the lifts as stands.
4. Exhaust all air from both cylinders by pushing both air control levers down at the same time.
5. Disconnect the air hoses and coil them on the hose holders on the back of each lift.




Figure 6
Downstop pawl and lug identification.

Lowering a Vehicle to the Ground

WARNING

To prevent serious injury or death from a falling vehicle, operate *both* air control levers *at the same time* and keep the vehicle level as it is raised or lowered.

WARNING

To prevent serious injury or death, clear the work area of all tools and equipment. Make sure all personnel are clear before lowering a vehicle.




Figure 7
Load retention pin.

1. Use this jack to lower the vehicle only if you used it to lift the vehicle. Using this jack to lower a vehicle that was raised with another device (or multiple devices) could overload this jack to the point of catastrophic failure.

Lowering a Vehicle to the Ground (continued)

WARNING

To prevent serious injury or death from a falling vehicle, operate *both* air control levers *at the same time* and keep the vehicle level as it is raised or lowered.

WARNING

To prevent serious injury or death, clear the work area of all tools and equipment. Make sure all personnel are clear before lowering a vehicle.

2. Remove the load retention pins and insert them into their holders.
3. Uncoil the air hoses from both lifts. Be sure the air hoses are free from all pinch points.
4. Position yourself at the front or rear of the vehicle so both lifts are visible. Face the vehicle and hold the air control unit with the air control levers pointing toward the vehicle and the quick couplers at the bottom of the air control unit.
5. Connect the air hose from the lift on your right to the right side of the air control unit and the air hose from the lift on your left to the left side of the air control unit (see Figure 4).
6. Connect the air supply to the air inlet port of the air control unit (see Figure 4).
7. Raise both lifts slightly (about 1/2") so the downstop pawls are raised above the downstop lugs.
8. At each lift, release the downstop pawl by pushing the downstop release handle toward the lift (see Figure 8.)
9. Lower the lifts by pushing both the air control levers down at the same time. Be sure to operate the air control levers so the vehicle stays level. Lower the lifts to their lowest position so the downstop pawls will automatically reset.




Figure 8

Step 7. Push downstop release handle toward lift.

CAUTION

If you decide to raise the vehicle again before it has been fully lowered, you must reset the downstop pawls. To manually reset the downstop pawls, pull the downstop release handle toward you on each of the lifts (see figure 8).

10. Place the vehicle transmission in gear (or park) and engage the brakes.
11. Disconnect the air hoses and coil them on each lift.
12. Move the Wheel Lifts away from the work area.

Using the Wheel Lifts with Support Stands

Transferring a Load to Support Stands

WARNING

To prevent serious injury or death from a falling vehicle, never put any part of your body under a vehicle supported by Wheel Lift System unless the lifts have the load retention pins properly inserted to pin the lifts as stands.

WARNING

To prevent serious injury or death from a falling vehicle, operate both air control lever at the same time and keep the vehicle level as it is lowered.

WARNING

Vehicles that are not supported evenly may shift and fall. To avoid serious injury or death by crushing, make sure that the stands used are the same height, and that they are positioned at the manufacturer's recommended locations the same distance from the Wheel lifts on each side of the vehicle.

After the vehicle has been raised (following instructions under the "Raising a Vehicle" section) and the wheel lifts have been pinned as stands ("Pinning the Lifts as Stand," section) you can transfer the vehicle to support stands and remove the wheel lifts, if you choose. Maintenance Instructions

1. Select stands of the same height for each side of the vehicle. Make sure the stands are capable of supporting the weight of the vehicle.
2. Identify appropriate manufacturer recommended locations, suitable for supporting the vehicle on stands, an equal distance from the Wheel Lifts on each side of the vehicle.
3. Clear the work area under the vehicle of all personnel, then place the stands at the appropriate locations on each side of the vehicle.
4. Remove the load retention pins and lower the vehicle down onto the support stands (if the load retention pins will not pull out easily, raise the vehicle just enough to free the load retention pins). Make sure the vehicle comes down evenly on the stands.
5. When the vehicle is securely supported by the support stands, lower the lifts to their lowest position so the down-stop pawls are automatically reset.

CAUTION

The downstop pawls will not automatically reset until lift has been fully lowered. If the lift is used without being lowered completely first, you must manually reset the downstop pawls by pulling the downstop release handle toward you on each of the lifts.

6. Disconnect the air hoses and coil them on the air hose holders on the back of each lift. Pull the Wheel Lifts away from the work area.

Removing Support Stands

1. Move the Wheel Lifts into place at opposite ends of the axle to be lowered and position them so the lift pads will cradle the tires when contact is made.
2. Carefully follow steps 7-10 under "Preparing the Lifts and Vehicle," section.
3. To raise the lifts, pull up on both air control levers at the same time. Operate the air control levers so both of the lift pads contact the tires at the same time.
4. Visually confirm that both lift pads have securely engaged the tires, and that the lift table tube of each lift contacts the side of the tire.
5. Raise the vehicle off the support stands by lifting up on both the air control levers at the same time. Be sure to operate the air control levers so the vehicle stays level.
6. Pin the lifts as stands, carefully following the instructions in "Pinning the Lifts as Stands," section.
7. Once the Wheel Lifts have been pinned as stands, remove the support stands from under the vehicle; then lower the vehicle, following the instructions under "Lowering A Vehicle To The Ground," section.

Maintenance Instructions


WARNING

To prevent serious injury or death from a falling vehicle, all inspection and maintenance procedures must be performed **after** the jack has been removed from service. Position the lifts so you have clear access to all sides of the lift for inspection and service.

The owner must inspect, or appoint a knowledgeable person to inspect, the jack. Visual inspection should be made before each use of jack, checking for abnormal conditions. Regular inspections should be made weekly for daily use and monthly for intermittent use. Each jack must be inspected immediately if subjected to an abnormal load or shock. Any jack which appears to be damaged in any way, is found to be badly worn, or operates abnormally shall be removed from service until necessary repairs are made.

1. All warning and capacity labels should be readable and complete. Wash external surfaces of jack, labels, and decals with a mild soap solution.
2. Lubricate all rotating and sliding portions of the jack monthly.

Figure 9
Lubrication points



Lift Table Adjustment

The Wheel Lift System has a 1/2-13 hex head capscrew mounted inside the top weldment to allow the lift table to be raised or lowered slightly. The capscrew has been adjusted at the factory to provide 1/4" to 5/16" of clearance between the bottom of the lift pads and the floor.

To raise or lower the lift table, follow the lift table adjustment steps below:

1. Place the Wheel Lifts on a level floor in a suitable open area.
2. Raise both lifts onto their lowest downstop.
3. Loosen the jam nut and turn the capscrew a few turns in the required direction. Clockwise raises the lift table, counterclockwise lowers it (see Figure 10 for identification.)
4. Tighten the jam nut.
5. Lower the Wheel Lift to its lowest position and check the lift table height above the floor.




Figure 10
Lift table clearance adjustment.

Repeat the adjustment as needed until each lift has a minimum of 1/8" clearance between the lift table bottom and the floor. With the lift table resting on the floor, the Wheel Lifts may not easily move around the shop floor.

Air Control Unit Cleaning Instructions

Occasionally, pieces of rust, scale or dirt from the air lines may become lodged under the rubber seals of the air control unit. This may cause minor air leakage and the Wheel Lift System units may slowly raise or lower even though the air control levers have not been actuated. This minor air leakage is easily corrected by following the steps below (refer to Figure 11 for component identification):

1. Disconnect the three air hoses attached to the air control unit.
2. Remove the valve bracket.
3. Remove the plug or plugs.
4. Use a stiff wire or pin punch to push the spool out of the valve body.
5. Carefully examine the rubber seal for any dirt or foreign material. If foreign material is embedded in the rubber seal, remove the screw and cup from the end of the spool, then remove and clean the rubber seal. Turn the seal over and reassemble it into the cup. Secure the cup back onto the end of the spool with the screw.
6. Lubricate the spool with a light chassis grease.
7. Insert the spool with O-ring into the air inlet spool port.
8. Insert the spool without O-ring into the air exhaust spool port.
9. Insert the spring(s).
10. Apply thread sealant to the plug(s) and install the plugs into the valve body. Do not over tighten the plug(s), as the threads can very easily be damaged.




Figure 11
Air Control Unit component identification

Structural Inspection



WARNING

To prevent serious injury or death from a falling vehicle, all inspection and maintenance procedures must be performed **after** the jack has been removed from service. Position the lifts so you have clear access to all sides of the lift for inspection and service.



WARNING

The jack must be removed from service and inspected for damage immediately if the jack is subjected to an abnormal shock or load. Never return the Wheel Lift System to service until all damaged components have been properly repaired or replaced. Always test the lift and verify proper operation before returning this device to service.

NOTICE

The owner must inspect, or appoint a knowledgeable person to inspect the jack for signs of corrosion and / or excessive wear. Visual inspection should be made before each use of jack, checking for abnormal conditions. Regular inspections should be made weekly for daily use and monthly for intermittent use. Each jack must be inspected immediately if subjected to an abnormal load or shock. Any jack which appears to be damaged in any way, is found to be badly worn, or operates abnormally shall be removed from service until necessary repairs are made.

1. Inspect the lifts for any cracks, chips, or signs of excessive wear. Visually inspect the welds.
2. Inspect the load retention pins for deformities or excessive wear - if the deformities or wearing away of material are easily noticeable without close inspection, it is excessive. Test the load retention pins by inserting them through the lift stop bar and into each downstop lug. If the load retention pin cannot be inserted fully through the lift stop bar and into each of the holes in the downstop lugs in all positions, it is excessively damaged and must be replaced before the lift can be used again.
3. Inspect the holes for the load retention pins in the base post. If these holes show excessive elongation or wear on the top or bottom surfaces, they must be repaired before the lift can be placed back into service. Contact customer service at the address and numbers on the back cover of this manual for repair recommendations. If any irregularities or problems are detected during an inspection, the jack must be removed from service immediately and repaired. Contact customer service at the address and numbers on the back cover of this manual.

Air Hose Inspection



WARNING

To prevent serious injury or death from a falling vehicle, or possible serious injury due to bursting air hoses, replace air hoses only with single-wire reinforced air hoses from manufacturer, part number 1-271-02002. The use of any other air hose increases the risk that the air hose may become pinched or damaged, resulting in failure of the air hose or of the lift during operation. Call customer service.

Inspect the air hoses daily for any signs of cuts, abrasions, or excessive wear. If any air hose appears to be damaged, replace it immediately with manufacturer authorized reinforced steel air hose, part number 1-271-02002. Inspect the air fittings daily for cracks and/or damaged parts. If any show damage, replace them before putting the Wheel Lift System back into service.

Troubleshooting

This section is a list, in which may be encountered and their solutions. If the solution listed fails to correct the problem, call customer service at the address and numbers on the back cover of this manual. Please have the model number, and serial number of your jack available. The serial number is permanently stamped to the top of the cylinder head plate.

PROBLEM	CAUSE / SOLUTION
Will not raise load	Inadequate air pressure, requires 145-psi. Lifts are overloaded. Rated capacity is 10,000 lbs. per lift. Air hoses are not connected properly, damaged, or pinched. Air control unit is dirty or damaged. See the "Air Control Unit Cleaning Instructions" section of this manual.
Only one lift raises	Air hose is not connected properly, damaged, or pinched. Air control unit is dirty or damaged. See the "Air Control Unit Cleaning Instructions" section of this manual.
Will not cradle tire	Tire is under-inflated or tire diameter is too large. Lift is not fully lowered. Vehicle is overloaded. Use other lifting means.
Lift will not lower or lowers erratically	Vehicle parking brake is set and/or transmission is in gear. Air hoses are not connected properly. Air hoses are pinched. Remove load from Wheel Lifts using other lifting means; remove air hoses from pinch point.
Lift table hits floor	Floor is uneven and/or rough. Raise Wheel Lift to lowest downstop. Lift table height needs adjustment for minimum clearance. See the "Lift Table Adjustment" section of this manual.
Lift raises slowly	Low air pressure. Raise air pressure to 145 psi. Air control unit is dirty or damaged. See the "Air Control Unit Cleaning Instructions" section of this manual. Lifts overloaded. Rated capacity is 10,000 lbs. per lift. Use other lifting means.

REPLACEMENT PARTS

Not all components of the wheel lift system are replacement items, but are illustrated as a convenient reference of location and position in the assembly sequence. When ordering parts, give Model number, parts number and parts description. Contact us for current pricing: Hein-Werner Customer Support, 10939 N. Pomona Ave. Kansas City, MO 64153; e-mail: customerservices@heinwerner-automotive.com Phone:(816) 891-6390



Use ONLY manufacturer provided or authorized replacement parts when servicing this Wheel Lift System!
Repair of this device requires special training, knowledge, and equipment. Refer all repairs to qualified personnel.




Figure 12- Air Control Unit

Air Control Unit Repair Kit List

Item	Qty	Part Number	Description
1	1	1-312-91011	Valve Bracket
2	1	4-312-91013	Valve Body
3	4	1-275-21004	Plug
4	4	1-312-91002	Spool
5	4	1-312-91003	Cup
6	2	0-390-00005	O-Ring
7	4	1-233-12001	Spring, Compression,
8	1	0-200-31113	Capscrew, Hex Head, 5/16-18 UNC
9	4	0-202-10601	Screw, Binder Head, #6-32 UNC
10	2	1-232-20126	Lever Handle Drilled
11	2	0-203-51003	Nut, 1/4 Palnut
12	1	8-009-60038	Bar, Round, 1/4"
13	4	1-390-10006	Seal
14	1	1-203-01102	Coupler Plug, Male, 1/4-18 NPT
15	2	1-272-12003	Nut, Hex
16	2	1-274-02004	Adapter, 90, Ext. Pipe / Int. Pipe
17	5	1-353-49158	Expansion Plug
18	1	1-312-91004	Screen

Replacement Parts Illustration for HW93693 (see pg. 16 for parts list)




Figure 13




Figure 14

Replacement Parts List for HW93693

(refer to Figures 13, 14 on pages 15)

Item	Qty	Part No.	Description
1	2	203-01200	Nut, Hex, 3/8-16
2	3	204-11201	Washer, Lock, 3/8
3	1	275-11001	Elbow, Street, 1/4 NPT, 90°
4	1	870-02015	Weldment, Back Cover
5	1	272-12002	Quick Disconnect
6	9	200-31206	Capscrew, Hex Head, 3/8-16UNC,
7	1	271-02001	Hose Assembly
8	2	870-04085	Pin Support Bracket
9	2	204-11103	Lock Washer, 5/16
10	2	200-31102	Capscrew, Hex Head, 5/16-18UNC
11	1	203-01400	Nut, Hex, 1/2-13 UNC
12	1	202-01413	Capscrew, Hex Hd., 1/2-13-UNC
13	2	200-31708	Capscrew, Hex Head, 3/4-10-UNC
14	2	204-01711	Washer, Special
15	2	233-15005	Spring, Compression
16	2	870-02020	Caster Ext. Weldment
17	8	203-01202	Nut, Hex, 3/8 - 16UNC
18	2	480-11038	Caster, 4" Dia.
19	2	233-15003	Spring, Compression 1 3/4 OD
20	2	870-04007	Spring Guide Pin
21	2	892-02007	Caster Pivot Arm Weldment
22	1	870-02010	Base Weldment
23	2	480-00035	Wheel
24	1	870-02011	Top Weldment
25	1	310-45037	Piston & Cup Subassembly
26	1	390-15007	Wiper Ring
27	1	200-31620	Capscrew, Hex Head, 5/8 - 11UNC
28	3	203-01601	Nut, Hex, 5/8-11 Self Locking
29	3	204-01614	Washer

Item	Qty	Part No.	Description
30	2	801-04062	Stop Block
31	2	235-21023	Roll Pin, 1/4 Dia., 1 3/8"L
32	2	870-02017	Downstop Release Handle Weldment
33	2	232-20127	Grip
34	2	203-51003	Nut, 1/4 Palnut, 1/4 Dia.
35	2	233-02008	Spring, Extension
36	2	202-01708	Capscrew, Special, 3/4-10UNC
37	4	230-11004	Retaining Ring
38	2	470-21006	Shaft, Grooved End
39	2	203-01705	Nut, Hex, 3/4-10UNC
40	1	203-11900	Nut, Hex, Jam 1-8UNC
41	2	441-24001	Bearing, Flanged, 1 1/2 Nom. I.D. X 1 5/8 O.D. X 1 1/2" L
42	1	480-00007	Grease Fitting Subassy
43	1	441-03001	Bearing, Cylindrical, 1.500 O.D. X 1.030 I.D
44	1	202-01900	Bolt, Hex Head, 1 - 8UNC
45	1	230-11000	"E"-Ring, 1/2 Dia.
46	1	204-01401	Washer, Flat
47	1	391-05005	Packing
48	1	310-45036	Piston Weldment
49	2	202-01600	Capscrew, Special, 5/8 - 11 UNC
50	2	234-39011	Hook, S-Type
51	1	203-51200	Nut, 3/8 PALNUT
52	1	870-04064	Stand Pin, Wheel Lift
53	1	234-32036	Chain, Jack
54	1	232-20116	Handle Grip
55	2	441-59003	Bearing
56	4	205-01006	Rivet
57	4	203-51002	Nut, 1/4 PALNUT



Use ONLY manufacturer provided or authorized replacement parts when servicing this Wheel Lift System! Repair of this device requires special training, knowledge, and equipment. Refer all repairs to qualified personnel.




Figure 15




Figure 16

Information Placard Location / Misc. Parts




Figure 17

Information Placard / Misc. Parts List

Item	Qty	Part Number	Description
1	1	670-10413	Information Placard, Air Hose Replacement
2	1	670-10176	Information Placard, Multi-Language
3	1	670-10412	Information Placard, Warning, Hose Pinching
4	1	870-00003	Final Assembly, Wheel Lift
5	2	232-20001	Hand Grip
6	2	200-31008	Capscrew, Hex Head
7	1	870-04078	Handle
8	1	670-10329	Information Placard, Warning, Operating Instructions, Wheel Lift System
9	1	670-10411	Information Placard, Warning & Instruction, Spanish
10	1	670-10408	Information Placard, Downstop Pawl
11	1	670-10410	Information Placard, Warning,
12	1	HW93693-L0	Identification Placard
13	1	670-10409	Information Placard, Tire Placement
14	1	680-10051	Shipping Pallet, 52 X 42 (Not Shown)
15	1	928048	Information Folder, Receiving and Unpacking



Use ONLY manufacturer provided or authorized replacement parts when servicing this Wheel Lift System! Repair of this device requires special training, knowledge, and equipment. Refer all repairs to qualified personnel.



TWO YEARS LIMITED WARRANTY

For a period of two (2) years from date of purchase, SFA Companies will repair or replace, at its option, without charge, any of its products which fails due to a defect in material or workmanship under normal usage. This limited warranty is a consumer's exclusive remedy.

Performance of any obligation under this warranty may be obtained by returning the warranted product, freight prepaid, to SFA Companies Warranty Service Department, 10939 N. Pomona Ave., Kansas City, MO 64153.

Except where such limitations and exclusions are specifically prohibited by applicable law:

- (1) THE CONSUMER'S SOLE AND EXCLUSIVE REMEDY SHALL BE THE REPAIR OR REPLACEMENT OF DEFECTIVE PRODUCTS AS DESCRIBED ABOVE
- (2) SFA COMPANIES SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGE OR LOSS WHATSOEVER.
- (3) ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO TWO YEARS, OTHERWISE THE REPAIR, REPLACEMENT OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.
- (4) ANY MODIFICATION, ALTERATION, ABUSE, UNAUTHORIZED SERVICE OR ORNAMENTAL DESIGN VOIDS THIS WARRANTY AND IS NOT COVERED BY THIS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.