



MODEL 66300B
3 TON LOW PROFILE
FLOOR JACK
USER'S MANUAL




*This hydraulic jack conforms to all "ANSI / ASME" safety standards.

Jackco Transnational Inc. © 2010
South El Monte, CA
888-452-2526

To see more jackco products please visit our website at www.jackco.com

FOR YOUR SAFETY

- Read these safety instructions carefully and keep this manual in an easy to find place as you may need to use it again.
- Non-compliance with these rules may result in injury or damage to the jack or the vehicle.
- Do not modify the jack in any way.
- Never exceed the rated capacity of the jack.
- This jack is a lifting device only and should never be used to move the vehicle.
- The jack should be supported on a solid and level ground. Never use the jack in a surface where it may sink into the ground.
- Ensure that there are no persons inside the vehicle to be lifted. Switch off the engine and apply the brake.
- Position the jack under the manufacturer's recommended lifting point for the vehicle. Off-centered loads can slip and accidents may result.
- During raising and lowering of the load, precautions should be taken to avoid movement of the vehicle. Traffic may cause the raised vehicle to rock during roadside use of the jack.
- Never work under a raised vehicle without supporting it with mechanical/jack stands.
- Never position any part of your body near the movable parts of the jack.
- Ensure that there are no persons or obstructions underneath the vehicle prior to lowering.
- Do not adjust the overload bypass valve under any circumstance.



Use wheel chocks appropriately.

SPECIFICATION

Capacity:	3 ton	Saddle Diameter :	4.7 in
Min Height :	4.3 in	Strokes to Max Height:	8
Max Height :	20.25 in	Net Weight :	105.6 lbs
Dimension:	29.75 in (L) x 14.2 in (W)		

PRIOR TO OPERATION

Air may become trapped in the hydraulic system during transit.

To Purge Air

1. Insert the handle into the socket and secure it with the set screw provided.
2. Turn the handle counterclockwise until release valve is open, pump the jack several times to purge the accumulated air in the system.
3. Turn the handle clockwise to close the release valve. The jack is now ready to use.

ASSEMBLY

Please refer to the exploded view drawing in this manual in order to identify parts:

1. Assemble the two handle halves together by depressing the spring-loaded button on the knurled handle section (#7) and inserting the upper handle section into the lower section (#8). The spring-loaded button should engage with the hole in the lower handle section.
2. Grease the inside of the handle yoke (#11) and remove the handle set screw (#10).
3. Install the handle assembly in the handle yoke until the bottom of the handle engages with the universal joint assembly (#13).
4. Reinstall the handle set screw in the handle yoke making sure the screw secures the handle to the handle yoke. Tighten the screw.
5. Air may become trapped in the hydraulic system during shipping and handling. Trapped air will affect the pumping performance of the jack. If this occurs, follow the air pumping procedure below:
 - a) Remove the four screws that secure the cover plate (A) to the jack frame (B) so the oil filler screw (#37) can be removed from the hydraulic power unit reservoir tube (#38).
 - b) With the lift arm (C) in its down position, look inside the oil fill screw hole. You should be able to see the top of the power unit's cylinder (#35). The hydraulic fluid level should be no higher than the top of the cylinder. Correct the fluid level if it is not at the proper height.
 - c) Pump the jack against a load that is at least 500 lbs. (225 Kgs).

After the load is raised, slightly turn the lift handle in a counterclockwise rotation so the load is very slowly lowered.


While the lift arm is lowering, quickly pump the lift handle 5 or 6 full incremental pump strokes. After pumping, lower the lift arm to its full rest position.
 - d) Install the oil fill screw (#37). Rotate the handle in a clockwise rotation until tight and pump the lift arm to maximum height.

If the pumping condition has improved, repeat steps "a" through "d" until all of the air has been purged from the system.


- e) Install the cover plate (A) with the four screws.

OPERATING INSTRUCTION

To Lift a Vehicle:




Turn the handle clockwise.
Move the handle up and down. Use the full stroke of the piston for greater speed.



Support the vehicle with appropriate jack stands.


To Lower a vehicle:



Lift the vehicle to remove the jack stands, ensuring that there are no persons or obstructions under the vehicle. Turn the handle counter-clockwise.

MAINTENANCE

Important: Both the maintenance and repair of the jack may only be performed by qualified persons, who have sufficient knowledge of the hydraulic system used in these jacks



Regularly lubricate the moving parts in the wheels, arms, handle and pump roller pin.

- Only original replacement parts should be used.

Extremely Important: never use brake fluid.


- When the jack is not in use, make sure the lifting arm is fully retracted to avoid corrosion.
- Keep the jack in a clean, dry place and out of children's reach.
- Replace the hydraulic fluid in the reservoir at least once a year. To check the hydraulic fluid level, lower the lifting arm completely.
- The hydraulic fluid level should be just below the filler plug. Replenish if necessary, and reinstall the rubber filler plug. Excessive hydraulic oil may render the jack inoperative.
- Inspect the jack before each use. Take corrective action or remove the jack from service if any of the following problems are found:
 - a. Cracked or damaged frame
 - b. Leaking hydraulic fluid
 - c. Scored, damaged piston rod
 - d. Loose hardware
 - e. Modified equipment
- Keep warning labels and instructional decals clean and readable. You may use a mild soap solution to wash external surfaces of the jack.

TROUBLESHOOTING

Caution: To prevent personal injury, all inspection, maintenance, and repair procedures must be performed when the jack is free of load.


Trouble	Solution
Jack will not lift load or leaks down excessively	<ol style="list-style-type: none">1. The release valve is not closed. Turn the valve clockwise tightly. If this does not work, remove handle, lubricate handle receptacle and handle end, then retry.2. Low on hydraulic fluid. Follow Step 5 of the "ASSEMBLY" procedure on page 3.3. Pump seals or back-up ring may be defective. Clean hydraulic fluid passages, replace seals and refill hydraulic fluid. (Must be serviced by qualified service center)
Jack will not lift to its full height	1. Low on hydraulic fluid. Follow Step 5 of the "ASSEMBLY" procedure on page 3.
	2. The hydraulic system has trapped air. Follow Step 5 of the "ASSEMBLY" procedure on page 3.
Jack will not lower completely	Return spring is broken or linkages are binding. Replace spring if broken. Grease pivot shaft and all lift arm linkages.
Jack will not lift smoothly or jack feels spongy	The hydraulic system has trapped air. Follow Step 5 of the "ASSEMBLY" procedure on page 3.
Jack will not hold load or handle rises	Discharge ball is not sealing hydraulic system and oil may be dirty. Manually flush hydraulic system. Open the release valve, as required, to raise and lower the lift arm. Manually raise and lower lift arm.

PARTS LIST



Part No.	Description	Q'ty	Part No.	Description	Q'ty
1	Retaining Ring	2	11	Handle Yoke	1
2	Washer	2	12	Power Unit Ass'y.	1
3	Front Wheel	2	13	Universal Joint Ass'y.	1
4	Rear Caster Ass'y.	2	14	Block Linkage (incl. Split Pin, Ret. Rings)	1
5	Hex Nut & Lock Washer	2	15	Grease Fitting	1
6	Yoke Retaining Bolt & Washer	2	16	Retaining Ring	2
7	Handle Lever "B"	1	17	Saddle	1
8	Handle Lever "A "	1	18	Saddle Screw	1
9	Handle Bumper	1	19	Rubber Saddle Pad	1
10	Set Screw - Handle	1	20	Spring	2

Model 66300B Power Unit



Index No.	Description	Q'ty	Index No.	Description	Q'ty
1	Ram	1	20	Back-Up Washer 15 x 10.6 x 1.25	2
2	Retaining Ring 30	1	21	Washer	1
3	Ram Bearing	1	22	Dust Cover	1
4	Gasket	1	23	Pump Spring	1
5	O-Ring 31 x 4.6	1	24	O-Ring	1
6	Cylinder Nut	1	25	Steel Ball 6	1
7	O-Ring 29.6 x 3.5	1	26	Steel Ball 5	1
8	Gasket	1	27	Retaining Ring 20	1
9	Steel ball 4	1	28	Large Pump Piston	1
10	Relief Valve Spring	2	29	O-Ring 15 x 2.65	2
11	Relief Valve Bolt	2	30	Back-Up Washer 20 x 15.6 x 1.25	2
12	Sealed Washer	2	31	Washer	1
13	Small Pump Housing	1	32	Large Pump Housing	1
14	Pump Spring	1	33	Hydraulic Block	1
15	Dust Cover	1	34	Cylinder Seal	1
16	Retaining Ring 15	1	35	Cylinder	1
17	Small Pump Piston	1	36	Gasket	1
18	Universal Joint Assembly	1	37	Oil Fill Screw	1
19	O-Ring 10 x 2.65	2	38	Reservoir Tube	1

*Index numbers are for your reference only, not all parts are available separately.

LIMITED ONE YEAR WARRANTY

Jackco Transnational Inc. warrants all Jackco equipment and tools to the original purchaser against any manufacturing defect in material or workmanship for a period of one (1) year from the original date of purchase. If the defective equipment or tool is determined to be covered under this warranty, it shall be repaired or replaced at manufacturer's discretion without charge, provided that the equipment or tool must be returned with proof of purchase to the dealer and freight prepaid, if returned to the manufacturer. This warranty shall not apply to damage due to accident, negligent use, and lack of maintenance, abuse or applications other than the specific function the equipment or tool is designed for.

No other warranties, expressed or implied, including those of merchantability or fitness for particular purpose shall be applicable to Jackco except as specifically stated herein. In no event shall Jackco be liable to any party for any special, direct, indirect, consequential, punitive damage of any nature caused by the sale or use of the equipment or tool.

Note: This warranty gives the original purchaser specific legal rights which may vary from state to state.

Jackco Transnational Inc. © 2010
South El Monte, CA
888-452-2526 www.jackco.com