

Setup
Assemble the Handle

- 1. Loosen the bolt on the handle socket.
- 2. Insert the handle.
- 3. Tighten the bolt.

Bleed Air from the Service Jack

Air can accumulate within a hydraulic system during shipment or after prolonged use. This entrapped air causes the jack to respond slowly or feel "spongy." To remove the air:

- 1. Open the release valve by turning the release knob counterclockwise.
- 2. Pump the jack handle six full strokes.
- 3. Close the release valve by turning the release knob clockwise.
- 4. If the jack does not immediately respond, repeat Steps 1-3.

Operating Instructions

(Refer to illustratibns above)

Control rod in Position A: Allows you to pump the jack using the handle.

Control rod in Position B: Locks the handle in place in three different positions.

- 1. Connect the shop air supply to the jack. (Shop air should be clean, dry, and regulated at 85-142 psi.)
- 2. Turn release knob completely counterclockwise, and place the control rod in Position A.
- 3. Position the jack under the vehicle using the manufacturer's recommended lifting points on the chassis. The jack must be free to roll without any obstructions while lifting or lowering the vehicle. The wheels of the vehicle must be in the straight-ahead position, with the emergency brake released.
- 4. Turn the release knob on the jack completely clockwise. Operate the air valve, pump the jack handle, or pump the foot pedal until the saddle touches the vehicle. Check the placement of the saddle lugs. Finish lifting the vehicle.
- 5. Place approved safety stands under the vehicle at points that will provide stable support. Before working on the vehicle, SLOWLY lower the vehicle onto the safety stands by turning the release knob counterclockwise.

Preventive Maintenance


IMPORTANT: Dirt is the greatest single cause of failure in hydraulic units. Keep the service jack clean and well lubricated to prevent foreign matter from entering the system. If the jack has been exposed to rain, snow, sand, or grit, it must be cleaned before it is used.

- 1. Store the jack in a well-protected area where it will not be exposed to corrosive vapors, abrasive dust, or any other harmful elements.
- 2. Refer to the illustration, and regularly (at least once per month) lubricate the moving parts shown.
- 3. Add grease to upper arm grease nipple (shown) every three months.
- 4. If necessary, add approved anti-wear hydraulic jack oil.**IMPORTANT: The use of alcohol, hydraulic brake fluid, detergent motor oil, or transmission oil could damage the seals and result in jack failure.**
- 5. Inspect the jack before each use. Take corrective action if any of the following problems are found:
 - a. cracked or damaged housing
 - b. excessive wear, bending, or other damage
 - c. leaking hydraulic fluid
 - d. scored or damaged piston rod
 - e. malfunctioning swivel heads or adjusting screws
 - f. loose hardware
 - g. modified or altered equipment

Troubleshooting Guide

Repair procedures must be performed in a dirt-free environment by qualified personnel who are familiar with this equipment.

Trouble	Cause	Solution
Jack does not lift	1. Release valve is open. 2. Low/no oil in reservoir. 3. Air-locked system. 4. Load is above capacity of jack. 5. Delivery valve and/or bypass valve not working correctly. 6. Packing worn out or defective. 7. Leak in air line. 8. Inadequate air pressure.	1. Close release valve. 2. Fill with oil and bleed system. 3. Bleed system. 4. Use correct equipment. 5. Clean to remove dirt or foreign matter. Replace oil. 6. Install seal kit. 7. Locate leak; tighten connections or replace hose. 8. Set air pressure to 85–142 psi.
Jack lifts only partially	1. Too much or not enough oil.	1. Check oil level.
Jack advances slowly	1. Pump not working correctly. 2. Leaking seals.	1. Install seal kit, or replace power unit. 2. Install seal kit.
Jack lifts load, but doesn't hold	1. Cylinder packing is leaking. 2. Valve not working correctly (suction, delivery, release, or bypass). 3. Air-locked system.	1. Install seal kit. 2. Inspect valves. Clean and repair seat surfaces. 3. Bleed system.
Jack leaks oil	1. Worn or damaged seals.	1. Install seal kit.
Jack will not retract	1. Release valve is closed.	1. Open or clean release valve.
Air motor won't run or runs erratically	1. Leak in air line. 2. Inadequate air pressure. 3. Air piston is sticking.	1. Locate leak; tighten connections, or replace hose. 2. Set air pressure to 85–142 psi. 3. Lube air motor by adding a small amount of oil to jack's air inlet.



5 TON / 10 TON
PNEUMATIC LONG FLOOR JACK
CRIC-LONGUE PNEUMATIQUE



FOR YOUR SAFETY

Please read these instructions carefully and retain them for future use.

Included: one set of pump core seals.

SPECIFICATIONS


Lifting Capacity (Ton)	Lifting Height (mm)	Max. Height (mm)	Min. Height (mm)	Gross Weight (Kgs)	Net Weight (Kgs)	Package Size (cm)	All Pressure (Mpa)
5TON	410	≥ 560	≤ 150	117	97	160x44x31	0.7-1.0
10TON	400	≥ 560	≤ 160	172	147	171x53x36	0.7-1.0

WARNING!!

- 1. This is a lifting device ONLY. Do not move or dolly the vehicle while on the jack.
- 2. Position this jack to ONLY lift on the areas of the vehicle as specified by the vehicle manufacturer.
- 3. After lifting the vehicle, ALWAYS support the load with appropriately rated vehicle support stands BEFORE working on the vehicle.
- 4. Do not overload this jack beyond its rated capacity. Overloading can cause damage to or failure of the jack.
- 5. This jack is designed ONLY for use on hard level surfaces capable of sustaining the load. Use on other than hard level surfaces can result in jack instability and possible loss of load.
- 6. Center load on jack saddle BEFORE lifting vehicle. Off-center loads and loads lifted when the jack is not level can cause loss of load or damage to the jack.
- 7. Study, Understand and follow all instructions in this manual BEFORE operating the jack.
- 8. Failure to head these warnings may result in loss of load, damage to the jack and/or jack Failure resulting in personal injury or Property damage.

Part List

Item No.	Description	Qty	Item No.	Description	Qty	Item No.	Description	Qty	Item No.	Description	Qty
2	Front Wheel	2	27	Snap Ring	1	52	Cylinder Pump Plunger	1	77	Washer	3
3	Washer	2	28	Washer	2	53	Pin	1	78	Screw	3
4	Snap Ring	4	29	O-ring	1	54	Steel Ball	1	79	Rod Joint	1
5	Grease Fitting	3	30	Piston Rod	1	55	Ball Seat	1	80	Spring	1
6	Rod Link	2	31	Piston Ring	1	56	Spring	1	81	Universal Joint Assy	1
7	Bolt	2	32	Sealing Washer	1	57	Screw	1	82	Convey Rod	1
8	Saddle	1	33	O-ring	1	58	Sealing Washer	1	83	Washer	1
9	Lockwasher	2	34	O-ring Retainer	1	59	Bolt	1	84	Pin	2
10	Nut	2	35	Snap Ring	1	60	Steel Ball	1	85	Copper Washer	1
11	Spring	1	36	Oil Cylinder Assembly	1	61	Spring	1	86	Pump Cylinder	1
12	Bolt	4	37	Oil Filler Plug	1	62	Copper Washer	1	87	Oil Seal	1
13	Bolt	1	38	Steel Ball	2	63	Bolt	1	88	Washer	1
14	SnapRing	4	39	Steel Ball	1	64	O-ring	2	89	Copper Washer	1
15	Shaft	2	40	Spring	1	65	Washer	2	90	Nut	1
16	Rear Wheel	2	41	Copper Washer	1	66	Handle Socket	1	91	Bolt	8
17	Nut	4	42	Bolt	1	67	Pedal	1	92	Front Cover	1
18	Snap Ring	2	43	Steel Ball	1	68	Nut	1	93	Steel Ball	1
19	Shaft	1	44	Spring	1	69	Washer	1	94	Air Pump Housing	1
20	Washer	1	45	Steel Ball	1	70	Bolt	1	95	Nut	1
21	Pin	1	46	Spring	1	71	Handle	1	96	Spring	1
22	Connecting Bar	1	47	Copper Washer	1	72	Sleeve	2	97	Cylinder Pump Plunger	1
23	Spring	1	48	Bolt	1	73	Knob	1	98	Pistom Body "A"	1
24	Snap Ring	2	49	Sealing Washer	1	74	Pin	1	99	O-ring	2
25	Shaft	1	50	Pin	1	75	Control Rod	1	100	Air Release	1
26	Cover Board	1	51	Release Valve Rod	1	76	Spring	1	101	O-ring	2



Item No.	Description	Qty
102	Piston Bobby "B"	1
103	Bolt	3
104	Air Seal	1
105	O-ring	2
106	O-ring	1
107	Rear Cover	1
108	Snap Ring	1
109	O-ring	2
110	Bolt	1
111	Air Valve	1