

Document Number	Document Revision	Document Revision Date
TD019	B	10/2018

Kit Part Number: TJ109LSRK

Kit Components: (1) Aluminum Reservoir, (1) Bladder, (6) Cap Screws 10-24 x 7/8", (1) Warning Decal, (1) Hyd. Oil, 1 quart.

IMPORTANT!

READ THESE INSTRUCTIONS COMPLETELY BEFORE ATTEMPTING TO INSTALL THIS KIT.

FAILURE TO FOLLOW THE STEPS IN PROPER SEQUENCE COULD CAUSE DAMAGE TO THE EQUIPMENT.

HOW TO INSTALL THE TRACK JACK RESERVOIR KIT:

STEP 1

Drain the oil completely out of the reservoir by removing the filler plug and tipping the jack on its side into a bucket. Discard used oil in accordance with all applicable laws and regulations.

STEP 2

Remove the six (6) socket head cap screws with a 5/32" Allen wrench. Then, separate the reservoir housing from the pump body. Discard the old reservoir housing, bladder and cap screws.

STEP 3

Thoroughly clean the underside of the reservoir mounting flange with rubbing alcohol.

STEP 4

Install new parts from KIT # TJ109LSRK. Apply the warning decal to the reservoir housing.

STEP 5

Fill reservoir with oil. Cycle the jack up and down several times to purge air. At each retract point, check the oil level and add additional oil as required. **With jack fully retracted, oil level must be up to top of reservoir.** Install the filler plug slowly to allow the oil to pass through the threads and then tighten it securely.

