




REPAIR PARTS LIST							
Item	Part Number	Quantity	Description	Item	Part Number	Quantity	Description
1	F372021	1	Acorn Nut	32	★ B1010803	1	O-Ring
2	F370245-1	1	Filler Plug	33A	DA10379147	1	Plastic Knob
3	F248570	1	Reservoir Cap	33B	F244010	1	Spindle
4	F241268	1	Reservoir Tube	34	F473900SR (see note A)	1	Piston Ass'y. (11-100)
5	F3107	1	Tie Rod		F475900SR (see note A)	1	Piston Ass'y. (11-400)
6	F368120	1	Hex Nut	35	★ F364049	1	Retaining Ring
7	★ B1147803	1	O-Ring	36	F304061	1	Beam Pin
8	F370245-1	1	Reservoir Drain Plug	37	F325132	1	Spacer (11-100)
9	F242005	1	Reservoir		F253132	1	Spacer (11-400)
10	M462028	2	Cap Screw	38	★ B1112803	1	O-Ring (11-100)
11	M462028	4	Cap Screw		★ B1010803	1	O-Ring (11-400)
12	★ B1008803	1	O-Ring	39	★ F326044	1	Back-Up Washer (11-100)
13	F373048	1	Screw		★ F324044	1	Back-Up Washer (11-400)
14	M462028	1	Cap Screw	40	F365212 (see note A)	2	Bearing
15	F239101	1	Base Plate	41	F327562	1	Guide Washer (11-100)
16	★ B1010803	1	O-Ring		F318562	1	Guide Washer (11-400)
17	F247268	1	Intake Tube	42	F299189	1	Beam Bracket
18	★ B1011803	1	O-Ring	43	M463028	4	Cap Screw
19	F157021	1	Gland Nut	44	F443132	1	Beam Spacer
19A	F73232	1	Sleeve (not shown, wired to Item 19)	45	★ F364049	1	Retaining Ring
20	F108006	1	Plug	46	F443132	1	Beam Spacer
21	G148190	1	Pump Body (11-100)	47	CK767060SR	1	Beam
	G149190	1	Pump Body (11-400)	48	F304061	1	Beam Pin
22	★ DA2472016	1	Ball	49	CL343550	1	Handle
23	G160061	1	Pin	50	F305070	1	Handle
24	★ DA2471016	1	Ball	51	see note B	1	Gauge
25	★ F319183	1	Spring	52	43704 (see note C)	1	Gauge Connector Kit
26	G147006	1	Hex Plug	53	P30718	1	Oil Screen
27	F160021	1	Gland Nut	54	C909087	1	Set Screw
28	F141006	1	Plug	—	A1026026	1	Name Plate
29	★ DA2471016	1	Ball	—	A1001003	2	Drive Screw
30	★ GB11167	1	Gasket		★ G423026	1	Decal
31	F246190	1	Release Valve Body				

★ Items included in and available only as part of Repair Kit 11000KU.

NOTE A: **IMPORTANT**—Bearing (Item 40) is "select fit" with the piston assembly (Item 34) and must be replaced whenever a new piston assembly is installed.

NOTE B: Gauge Part Numbers—T6001L through T6011L.

NOTE C: Gauge equipped models only.

Enerpac Worldwide Locations

Africa

ENERPAC Middle East FZE
Office 423, JAFZA 15
P.O. Box 18004
Jebel Ali, Dubai
United Arab Emirates
Tel: +971 (0)4 8872686
Fax: +971 (0)4 8872687

Australia, New Zealand

Actuant Australia Ltd.
Block V Unit 3
Regents Park Estate
391 Park Road
Regents Park NSW 2143
(P.O. Box 261) Australia
Tel: +61 297 438 988
Fax: +61 297 438 648

Brazil

Power Packer do Brasil Ltda.
Rua dos Inocentes, 587
04764-050 - Sao Paulo (SP)
Tel: +55 11 5687 2211
Fax: +55 11 5686 5583
Toll Free in Brazil:
Tel: 0800 891 5770
vendasbrasil@enerpac.com

Canada

Actuant Canada Corporation
6615 Ordan Drive, Unit 14-15
Mississauga, Ontario L5T 1X2
Tel: +1 905 564 5749
Fax: +1 905 564 0305
Toll Free:
Tel: +1 800 268 4987
Fax: +1 800 461 2456
Technical Inquiries:
techservices@enerpac.com

China

Actuant China Ltd.
1F, 269 Fute N. Road
Waigaoqiao Free Trade Zone
Pudong New District
Shanghai, 200 131 China
Tel: +86 21 5866 9099
Fax: +86 21 5866 7156

◆ e-mail: info@enerpac.com

Actuant China Ltd. (Beijing)

709B Diyang Building
Xin No. 2
Dong San Huan North Rd.
Beijing City
100028 China
Tel: +86 10 845 36166
Fax: +86 10 845 36220

Central and Eastern Europe, Greece

ENERPAC GmbH
P.O. Box 300113
D-40401 Düsseldorf
Willstätterstrasse13
D-40549 Düsseldorf
Germany
Tel: +49 211 471 490
Fax: +49 211 471 49 28

France, Switzerland francophone

ACTUANT - ENERPAC
France S.A., ZA de Courtaboeuf
32, avenue de la Baltique
91140 Villebon / Yvette
France
Tel: +33 1 60 13 68 68
Fax: +33 1 69 20 37 50

Germany, Austria and Switzerland

ENERPAC GmbH
P.O. Box 300113
D-40401 Düsseldorf
Willstätterstrasse13
D-40549 Düsseldorf
Germany
Tel: +49 211 471 490
Fax: +49 211 471 49 28

India

ENERPAC Hydraulics
(India) Pvt. Ltd.
Office No. 9,10 & 11,
Plot No. 56, Monarch Plaza,
Sector 11, C.B.D. Belapur
Navi Mumbai 400614, India
Tel: +91 22 2756 6090
Tel: +91 22 2756 6091
Fax: +91 22 2756 6095

Italy

ENERPAC S.p.A.
Via Canova 4
20094 Corsico (Milano)
Tel: +39 02 4861 111
Fax: +39 02 4860 1288

Japan

Applied Power Japan Ltd.
Besshochou 85-7
Saitama-shi, Kita-ku,
Saitama 331-0821
Japan
Tel: +81 48 662 4911
Fax: +81 48 662 4955

Middle East, Turkey and Caspian Sea

ENERPAC Middle East FZE
Office 423, JAFZA 15
P.O. Box 18004
Jebel Ali, Dubai
United Arab Emirates
Tel: +971 (0)4 8872686
Fax: +971 (0)4 8872687

Russia and CIS

(excl. Caspian Sea Countries)
Actuant LLC
Admiral Makarov Street 8
125212 Moscow, Russia
Tel: +7-495-9809091
Fax: +7-495-9809092

Singapore

Actuant Asia Pte. Ltd.
37C, Benoi Road Pioneer Lot,
Singapore 627796
Tel: +65 68 63 0611
Fax: +65 64 84 5669
Toll Free: +1800 363 7722
Technical Inquiries:
techsupport@enerpac.com.sg

◆ internet: www.enerpac.com

South Korea

Actuant Korea Ltd.
3Ba 717,
Shihwa Industrial Complex
Jungwang-Dong, Shihung-Shi, Kyunggi-Do
Republic of Korea 429-450
Tel: +82 31 434 4506
Fax: +82 31 434 4507

Spain and Portugal

ENERPAC
Avda. Los Frailes, 40 – Nave C & D
Pol. Ind. Los Frailesancho De Arriba
(Madrid) Spain
Tel: +34 91 661 11 25
Fax: +34 91 661 47 89

The Netherlands, Belgium, Luxembourg, Sweden, Denmark, Norway, Finland and Baltic States

ENERPAC B.V.
Galvanistraat 115, 6716 AE Ede
P.O. Box 8097, 6710 AB Ede
The Netherlands
Tel: +31 318 535 911
Fax: +31 318 525 613
+31 318 535 848

Technical Inquiries Europe:
techsupport.europe@enerpac.com

United Kingdom, Ireland

Enerpac Ltd
Bentley Road South
Darlaston, West Midlands
WS10 8LQ, United Kingdom
Tel: +44 (0)121 50 50 787
Fax: +44 (0)121 50 50 799

USA, Latin America and Caribbean

ENERPAC
P.O. Box 3241
6100 N. Baker Road
Milwaukee, WI 53209 USA
Tel: +1 262 781 6600
Fax: +1 262 783 9562

User inquiries:

+1 800 433 2766

Inquiries/orders:

+1 800 558 0530

Technical Inquiries:

techservices@enerpac.com

**All Enerpac products are guaranteed against defects in workmanship and materials for as long as you own them.
For your nearest authorized Enerpac Service Center, visit us at www.enerpac.com**