




PARTS BREAKDOWN

Parts List For Bead Push Off Tool 11080





PARTS BREAKDOWN

Parts List For

Bead Push Off Tool

11080

NO.	DESCRIPTION	QTY.
11080-001	Handle Grip	1
11080-002	Handle	1
11080-003	Cap Screw	1
16060	Coupler	1
11080-005	Bolt	1
11080-006	Spring	1
11080-007	Cylinder	1
11080-008	Elastic washer	1
11080-009	Washer	1
11080-010	Seal washer	1
11080-011	O ring	1
11080-012	O ring	1
11080-013	Piston	1
11080-014	Washer	1
11080-015	Piston Rod	1
11080-016	Extension	1
11080-017	Bolt	1
11080-018	Ring	1
11080-019	Hook	1
11080-020	Press Block	1