


# BLACKHAWK

REPAIR PARTS SHEET

**HAND JACK  
MODEL FA-27**

**RATED CAPACITY  
30-TON**

Sheet No. 1117 — Issued Feb. 1949  
Supersedes Sheet No. 755D



**REPAIR PARTS SHEET FOR FA-27 HYDRAULIC JACK**



Parts List on Reverse Side

# PARTS LIST FOR MODEL FA-27

Item No.	Part No.	Part Name	No. Req.
1	I.03	Drive Screw	6
2	FA27.05	Base	1
3	I.06-1	Base Plug	3
4	D11.10	Release Valve Spindle	1
5	E11.11	Release Valve Packing Nut	1
6	E11.12	Release Valve Handle Pin	1
7	I.16	Ball	2
8	SI.16	Ball	2
9	FA11.18	Oil Strainer Screen	2
10	FA11.20	Top Cap	1
11	FA11.21	Gland Nut	1
12	C9.22	Filler Plug	1
13	F27.23	Filler Plug Gauge	1
14	FA27.25	Reservoir	1
15	I.26D	Name Plate Transfer	1
16	I.26E	Name Plate	1
17	FA27.30	Cylinder	1
18	C9.37	Filler Plug Gasket	1
19	FA27.40	Plunger	1
20	FA11.41	Plunger Cup	1
21	FA11.43	Plunger Cup Spreader	1
22	FA11.45	Saddle	1
23	E14.50	Pump Cylinder	1
24	F11.50	Pump Cylinder	1
25	5.51	Pump Plunger	1
26	F14.51	Pump Plunger	1
27	E14.52	Pump Cup Spreader	1
28	F11.52	Pump Cup Spreader	1
29	F14.53	Pump Cup	1

Item No.	Part No.	Part Name	No. Req.
30	F11.53	Pump Cup	1
31	E14.54	Pump Gland Nut	1
32	F11.54	Pump Gland Nut	1
33	5.55	Pump Cup Retaining Nut	2
34	E14.55	Pump Cup Retaining Nut	1
35	I.56	Clevis	1
36	I.57-1	Clevis Pin	2
37	I.58	Cotter Pin	4
38	F11.59	Pump Gland Ring	1
39	F27.60	Beam	1
40	E27.60-1	Beam	1
41	D11.62	Link	2
42	I.63	Link Rivet	2
43	CB9.57	Link Pin	2
44	5.70	Pump Handle	1
45	FA11.71	Disc	1
46	FA27.72	Pull Handle	2
47	FA27.73	Pull Handle Rivet	8
48	D11.74	Release Valve Packing	4
49	E14.75	Pump Packing	4
50	F11.75	Pump Packing	3
51	FA11.76	Plunger Packing	3
52	SI.167B	Valve Plug Gasket	2
53	SI.183	Outlet Valve Spring	2
54	CB9.185	Valve Plug	2
57	P5.245	Pipe Plug	1
		Blackhawk Hydraulic Oil #30	
		275 Cu. In. (about 9 1/2 Pints)	

**NOTE:** No orders for parts can be filled unless both model and serial number of equipment is given.

## GUARANTEE

All Blackhawk Jacks are guaranteed against defects in workmanship and material. In case of such defects, repairs and adjustments will be made on a no charge basis, providing jack or jack parts are returned to one of our Authorized Repair Service Stations or the factory at Milwaukee by prepaid transportation for inspection. Guarantee does not cover jacks worn out in service, damaged through abuse, overloading or accident. This guarantee is VOID if anything but BLACKHAWK HYDRAULIC JACK OIL is used in jack. Do NOT USE brake fluids.

## BLACKHAWK AUTHORIZED REPAIR SERVICE STATIONS

**BLACKHAWK MFG. CO. - - - MILWAUKEE 1, WIS.**