ENERPAC
A UNIT OF APPLIED POWER INC.

Repair Parts Sheet

JH - 1.5, JH - 3, JH - 5, JH - 8, JH - 12, JH - 20

L-555
REV. A
2/92
PC 3205

Model Numbers

JH-1.5 . . . . 1½ Ton	JH-8 . . . . . 8 Ton
JH-3 . . . . . 3 Ton	JH-12 . . . . . 12 Ton
JH-5 . . . . . 5 Ton	JH-20 . . . . . 20 Ton



TO PROTECT YOUR WARRANTY, USE ONLY ENERPAC HYDRAULIC OIL

Parts List

Item No.	Part Number						Qty.	Description
	JH1.5	JH3	JH5	JH8	JH12	JH20		
1	AJ100.304	CJ100.102	EJ100.051	HJ100.053	KJ100.088	NJ100.024	1	Base
2	K995.025	CJ100.005	EJ100.004	HJ100.003	K553.025	K559.025	1	Reservoir
3	AJ100.021	CJ100.022	EJ100.021	EJ100.021	KJ100.019	NJ100.044	1	Plunger
4	02-6	04-6	06-6	06-6	12-6-1SR	------	1	Saddle Ass'y.
5	AJ100.018	CJ100.008	HJ100.004	HJ100.004	KJ100.007	NJ100.005	1	Cylinder
6	K515.020	K516.020	K517.020	K518.020	K519.020	K520.020	1	Top Cap
7	K584.900	K584.900	K584.900	K584.900	K584.900	K584.900	1	Pump Ass'y.
8	*B1017.503	*B1021.503	*B1027.503	*B1027.503	*B1031.503	*B1034.503	1	O-Ring
9	A8019.060	A8019.060	A8019.060	A8019.060	A8019.060	A8019.060	1	Beam
10	DA547.062	DA547.062	DA547.062	DA547.062	DA547.062	DA547.062	2	Link
11	CA237.950W	CA237.950W	CA237.950W	CA237.950W	CA237.950W	CA237.950W	1	Release Valve
12	K494.061	K494.061	K494.061	K494.061	K494.061	K494.061	1	Groove Pin
13	AJ100.063	AJ100.063	AJ100.063	AJ100.063	AJ100.063	AJ100.063	1	Beam Link Pin
14	AJ100.062	AJ100.062	AJ100.062	AJ100.062	AJ100.062	AJ100.062	1	Beam Pin
15	*B1001.058	*B1001.058	*B1001.058	*B1001.058	*B1001.058	*B1001.058	2	Cotter Pin
16	*B1317.562	*B1317.562	*B1317.562	*B1317.562	*B1317.562	*B1317.562	1	Back-Up Washer
17	*E221.041	*E221.041	*E221.041	*E221.041	*E221.041	*E221.041	1	Pump Cup
18	*SJ100.169	*SJ100.169	*SJ100.169	*SJ100.169	*SJ100.169	*SJ100.169	1	Washer
19	*A8002.021	*A8002.021	*A8002.021	*A8002.021	*A8002.021	*A8002.021	1	Retaining Nut
20	AJ100.061	AJ100.061	AJ100.061	AJ100.061	AJ100.061	AJ100.061	1	Valve Plug
21	*B159.167	*B159.167	*B159.167	*B159.167	*B159.167	*B159.167	1	Valve Plug Gasket
22	*AJ100.040	*AJ100.040	*AJ100.040	*AJ100.040	*AJ100.040	*AJ100.040	1	Valve Spring
23	*B1009.016	*B1009.016	*B1009.016	*B1009.016	*B1009.016	*B1009.016	1	5/16" Ball
24	*B1006.016	*B1006.016	*B1006.016	*B1006.016	*B1006.016	*B1006.016	1	7/32" Ball
25	*B1003.503	*B1003.503	*B1003.503	*B1003.503	*B1003.503	*B1003.503	1	O-Ring
26	B1006.123	B1006.123	B1010.123	B1010.123	B1014.123	B1018.123	1	Hex Nut
27	AJ100.023	B1026.108	B1034.108	EJ100.012	B1042.108	B1050.108	1	Washer
28	*AJ100.437	*CJ100.109	*EJ100.009	*EJ100.009	*KJ100.010	*NJ100.008	1	Plunger Cup
29	AJ100.050	K497.044	K512.044	K512.044	K525.044	NJ100.043	1	Plunger Ring
30	B1036.046	B1036.046	B1036.046	B1036.046	B1036.046	B1036.046	1	Filler Plug
31	*AJ100.020	*AJ100.020	*AJ100.020	*AJ100.020	*AJ100.020	*AJ100.020	1	Gasket
32	106-1	106-1	106-1	106-1	106-1	106-1	1	Flush Plug
33	K488.070	K488.070	K488.070	K488.070	K488.070	K488.070	1	Bar Handle (Not Shown)
34	K489.070	K489.070	K489.070	K489.070	K489.070	K489.070	1	Tube Handle (Not Shown)
35	CH649.026	CH651.026	CH653.026	CH655.026	CH657.026	CJ800.026	1	Name Plate (Not Shown)
36	G421.026	G421.026	G421.026	G421.026	G421.026	G421.026	1	Decal (Not Shown)
	JH15K	**JH3K**	**JH5K**	**JH8K**	**JH12K**	**JH20K**	**1**	**Repair Kit**

* Indicates Items Included in, and Available **Only** as a Part of the Repair Kit.

REPAIR AND SERVICE INFORMATION: For repair service and parts contact your nearest authorized ENERPAC Technical Service Center. The Authorized Enerpac Technical Service Center will provide complete and prompt service on all Enerpac products. For the location of an ENERPAC Service Center, call **Toll Free 1-800-558-0530. (In Canada CALL 1-800-268-6975)**

NOTE: This phone number is not for product repair information.

WARRANTY INFORMATION: All warranty repairs must be performed by an authorized Enerpac Technical Service Center. All Enerpac tools are guaranteed from date of delivery to user against defects in workmanship and materials. Free repair or replacement will be made on all items not standing up to this guarantee. Following manufacturers trade custom, however, chains cannot be guaranteed. Warranty does not cover ordinary wear and tear, abuse or misuse, overloading, altered products or use of improper fluids. For prompt handling, send items requiring repairs prepaid, to your nearest authorized Enerpac Technical Service Center. Warranty repair service for non-Enerpac components used on Enerpac products, should be obtained through an authorized Service Center representing the manufacturer of the item.

PRINTED IN U.S.A. MARCAS REGS.