

Repair Parts Sheet

**JH1.5, JH-3, JH-5, JH-8, JH-12, JH-20
Hydraulic Jacks**

L555


For date codes beginning with the letter "O".

Rev. F

05/98

PC3205

NOTE: Jack base, item 1, is not available as a service item.
Order complete jack.



INSTALL ALL KIT COMPONENTS TO INSURE OPTIMUM PERFORMANCE OF THE REPAIRED UNIT.

Repair Parts List							
Item	JH1.5	JH3	JH5	JH8	JH12	JH20	Qty. Description
1	AJ100304	CJ100102	EJ100051	HJ100088	KJ1000881	NJ100024	1 Base
10	K995025	CJ100005	EJ100004	HJ100003	K553025	K559025	1 Reservoir
3	AJ100021SR	CJ100022SR	EJ100021SR	EJ100021SR	KJ100019SR	NJ100044SR	1 Plunger (incl. item 4, 26,27,28,29)
8	02-6	04-6	06-6	06-6	12-6	-----	1 Saddle Ass'y.
2	AJ100018	CJ100008	HJ100004	HJ100004	KJ100007	NJ100005	1 Cylinder
13	K515020	K516020	K517020	K518020	K519020	K520020	1 Top Cap
16	K584900SR	K584900SR	K584900SR	K584900SR	K584900SR	K584900SR	1 Pump Ass'y. (incl. item 16,17)
14	B1017503	B1021503	B1027503	B1027503	B1031503	B1034503	1 O-ring
35	A8019060SR	A8019060SR	A8019060SR	A8019060SR	A8019060SR		1 Beam (incl. item 30, 31, 33, 34, and 30)
32	DA547062	DA547062	DA547062	DA547062	DA547062	DA547062	2 Link

Table continued on next page

Repair Parts List							
Item	JH1.5	JH3	JH5	JH8	JH12	JH20	Qty. Description
27	CA237950SR	CA237950SR	CA237950SR	CA237950SR	CA237950SR	CA237950SR	1 Release Valve (incl. item 29)
31	K494061	K494061	K494061	K494061	K494061	K494061	1 Groove Pin
33	AJ100062	AJ100062	AJ100062	AJ100062	AJ100062	AJ100062	1 Beam Link Pin
34	AJ100063	AJ100063	AJ100063	AJ100063	AJ100063	AJ100063	Beam Pin
30	B1001058	B1001058	B1001058	B1001058	B1001058	B1001058	2 Cotter Pin
26	AJ100061SR	AJ100061SR	AJ100061SR	AJ100061SR	AJ100061SR	AJ100061SR	1 Valve Plug (incl. it. 25)
25	B159167	B159167	B159167	B159167	B159167	B159167	1 Valve Plug Gasket
24	AJ100040	AJ100040	AJ100040	AJ100040	AJ100040	AJ100040	1 Valve Spring
22	B1009016	B1009016	B1009016	B1009016	B1009016	B1009016	1 5/16" Ball
21	B1006016	B1006016	B1006016	B1006016	B1006016	B1006016	1 7/32" Ball
29	B1003503	B1003503	B1003503	B1003503	B1003503	B1003503	1 O-Ring
7	B1006123	B1006123	B1010123	B1010123	B1014123	B1018123	1 Hex JamNut (std. hdw.)
6	AJ100437	EJ100109	EJ100009	EJ100009	KJ100010	NJ100008	1 Plunger Cup
5	AJ100023	B1026108	B1034108	B1034108	B1042108	B1050108	1 Washer
4	AJ100050	K497044	K512044	K512044			1 Plunger Ring
11	B1036046SR	B1036046SR	B1036046SR	B1036046SR	B1036046SR	B1036046SR	1 Filler Plug (incl. it. 12)
12	AJ100020	AJ100020	AJ100020	AJ100020	AJ100020	AJ100020	2 Pin
ITEMS 33-35 ARE NOT SHOWN ON THE PARTS DRAWING							
33	K488070	K488070	K488070	K488070	K488070	K488070	1 Bar Handle
34	K489070	K489070	K489070	K489070	K489070	K489070	1 Tube Handle
36	CJ649026	CJ651026	CJ653026	CJ655026	CJ657026	CJ800026	1 Name Plate
15	B1317562	B1317562	B1317562	B1317562	B1317562	B1317562	1 Backup Washer
	JH15K	JH3K	JH5K	JH8K	JH12K	JH20K	1 Repair Kit

Australia Enerpac Block V, Unit 3 Regents Park Estate 391 Park Road Regents Park NSW 2143 Tel: (61) (2) 743-8988 Fax: (61) (2) 743-8648	Eastern Europe and Other European Countries, Middle East and Africa Enerpac 47, avenue Blanc P.O. Box 67, CH-1211 Geneva 21, Switzerland Tel: (41) 22-731 94 05 Telex: 22-41 2843 Fax: (41) 22-731 12 15	France Enerpac B.P. 200 Parc d'Activités du Moulin de Massy 91882 Massy Cedex, France Tel: (33) 1-60 13 68 68 Telex: 600 951 Fax: (33) 1-69 20 37 50	Japan Enerpac 10-17 Sasame Kita-cho, Toda-Shi Saitama 335, Japan Tel: 81-0484-22-2251 (Administration) 0484-21-2311 (Sales) Telex: J26275 Fax: 82-0484-22-0596	Netherlands, Belgium, Luxemburg Enerpac Storkstraat 25/P.O. Box 269 NL-3900 AG Veenendaal Holland Tel: (31) 8385 35911 Fax: (31) 8385 25613/26645	United Kingdom Enerpac Leacon Road Ashford, Kent TN23 2TU England Tel: 4-4233-639871 Telex: 966 450 Fax: 4-4233-643923
Canada Enerpac 13000 West Silver Spring Drive Butler, Wisconsin 53007, USA Tel: (800) 426-4129 User Tel: (800) 426-2284 Distributor Fax: (414) 781-1049	Far East Enerpac 47 Jalan Pemimpin #01-02 & 01-03 Sin Cheong Building Singapore 2057 Thomson Road P.O. Box 114 Singapore 9157 Tel: (65) 2581677 Telex: RS24882 APOWR Fax: (65) 2582847	Germany Enerpac Mündelheimer Weg 51 P.O. Box 300 113 D-40401 Düsseldorf 30 Tel: (49) (221) 41707-0 Telex: 8582790 Fax: (49) (211) 4170740	Latin America and Caribbean Enerpac 13000 West Silver Spring Drive Butler, Wisconsin 53007 Tel: (414) 781-6600 ext. 263 Fax: (414) 781-5561	South Korea Enerpac 163-12, Dodang-Dong Choong-Ku, Buchun-Shi, Kyunggi-Do Republic of Korea Tel: (82) (32) 6560836/7 Fax: (82) (32) 6563002	United States Enerpac 13000 West Silver Spring Drive Butler, Wisconsin 53007, USA Tel: (414) 781-6600 1-800-433-2766 (End User) 1-800-558-0530 (Distributor) Fax: (414) 781-1049
APRUSS Enerpac Applied Power Moscow Leninsky Prospekt 95A 117313 Moscow Tel: (95) 9565090 Fax: (95) 9362005		Italy Enerpac Via Canova, 4 20094 Corsico Milano, Italy Tel: 39-2-4582741 Telex: 352337 Fax: 39-2-48601288	Mexico Enerpac Blvd. Gral. Felipe Angeles 1604 P.O. Box 362 Pachuca. Hidalgo 42080 Mexico Tel: (52) 771 3-3700 or Telex: 17 55 15 Fax: (52) 771 3-1196 or (52) 771 8-3800	Spain Enerpac Calle de La Imprenta, 5 Poligono Industrial 28100 Alcobendas, Madrid Spain Tel: (34) 1-6611125 Fax: (34) 1-6614789	



All Enerpac products are guaranteed against defects in workmanship and materials for as long as you own them. Under this guarantee, free repair or replacement will be made to your satisfaction.

For prompt service, contact your Authorized Enerpac Service Center or call toll free:

In U.S.A. 1-800-558-0530
In Canada 1-800-426-2284

RECYCLED PAPER

PRINTED IN U.S.A.