




WARNING: STOP RING ON RCH-1003 IS SPRING LOADED!

If not contained during disassembly, spring and stop ring could cause personal injury.



REPAIR PARTS LIST						
Item	Part Number					Qty. Description
	RCH-1003	RRH-1001	RRH-1003	RRH-1006	RRH-10010	
1	DA4249030	DA4329030	DA4249030	DA4784030	DA4314030	1 Cylinder
2	* B1108503	* B1108503	* B1108503	* B1108503	* B1108503	1 O-Ring
3	* DA4989566	* DA4989566	* DA4989566	* DA4989566	* DA4989566	1 Back-Up Ring
4	DA4250040	DA4328040	DA4250040	DA4785040	DA4315040	1 Plunger
5	* CF89044	* CF89044	* CF89044	* CF89044	* CF89044	1 Wiper Ring
6	* B1345514	* B1345514	* B1345514	* B1345514	* B1345514	1 G-T Ring Assembly
7	* B1437513	* B1437513	* B1437513	* B1437513	* B1437513	2 G-T Ring Assembly (RCH-1003 use 1)
8	DA4247900	DA4326900	DA4247900	DA4797900	DA4313900	1 Center Tube
9	* DA4270249	* DA4270249	* DA4270249	* DA4270249	* DA4270249	1 Retaining Ring
10	DA4265110	-----	-----	-----	-----	1 Spring
11	DA4248044	DA4327044	DA4248044	DA4248044	DA4248044	1 Stop Ring
12	* G316044	* G316044	* G316044	* G316044	* G316044	1 Wiper Ring
13	DA4244045	DA4244045	DA4244045	DA4244045	DA4244045	1 Saddle
14	CR400	CR400	CR400	CR400	CR400	2 Coupler (RCH-1003 use 1)
15	CD411	CD411	CD411	CD411	CD411	2 Dust Cap (RCH-1003 use 1) (Not Shown)
16	A1009245	-----	-----	-----	-----	2 Plug (RCH Models Only)
17	-----	CJ160900W	CJ160900W	CJ160900W	CJ160900W	1 Relief Valve Assembly
18	-----	* B1429514	* B1429514	* B1429514	* B1429514	1 G-T Ring Assembly
19	DA4591268	-----	DA4311044	DA4311044	DA4311044	1 Stop Tube, Inner Stop Ring
20	DA5178489	-----	DA5178489	DA5178489	DA5178489	2 Collar
21	DA5184070	-----	DA5184070	DA5184070	DA5184070	2 Handle
22	B1143046	-----	B1143046	B1143046	B1143046	2 Bolt
23	B1019066	-----	B1019066	B1019066	B1019066	2 Washer
24	B1009120	-----	B1009120	B1009120	B1009120	2 Nut
25	CL969039	-----	CL969039	CL969039	CL969039	2 Bushing
	RCH1003K4	RRH1001K4	RRH1001K4	RRH1001K4	RRH1001K4	1 Repair Kit
* Indicates items included in, and available only in Repair Kit listed above.						

Australia
ENERPAC, Applied Power Australia Ltd.
Block V Unit 3,
Regents Park Estate,
391 Park Road
Regents Park NSW 2143
(P.O. Box 261) Australia
Tel: +61 297 438 988
Fax: +61 297 438 648

Brazil
Power Packer do
Brasil LTDA
Avenida Ferraz
Alvim n° 1012
(09961-550) - Diadema
S°o Paulo, Brazil
Tel: +55 11 4051 1188
Fax: +55 11 4051 3699

China
Shanghai Blackhawk
Machinery Co Ltd
15H Jinxuan Building
238 Nandan Road (E)
Shanghai, 200030, China
Tel: +86 21 6469 8732
Fax: +86 21 6469 8721

France, Greece, Turkey, Middle East, Africa
ENERPAC S.A.
B.P. 200, Parc d'Activit s
du Moulin de Massy
F-91882 Massy CEDEX (Paris) France
Tel: +33 01 601 368 68
Fax: +33 01 692 037 50

Germany, Denmark, Scandinavia, Austria, Switzerland, Eastern Europe, CIS
ENERPAC
Applied Power GmbH
P.O. Box 300113
D-40401 D sseldorf, Germany
Tel: +49 211 471 490
Fax: +49 211 471 49 28/40

Holland, Belgium, Luxembourg,
ENERPAC B.V.
Storkstraat 25
P.O. Box 269
3900 AG Veenendaal, Holland
Tel: +31 318 535 911
Fax: +31 318 535 848
+31 318 526 645

Hong Kong
ENERPAC
Room 907 Workingberg
Commercial Building
41-47 Marble Road,
North Point
Tel: +852-2561 6295
Fax: +852-2561 6772

India
ENERPAC
Hydraulic (India) Pvt Ltd
Plot No. A-571
MIDC, TTC Industrial Area
Mahape-400 701,
Navi Mumbai, India
Tel: +91 22 769 47 78
Fax: +91 22 769 84 73

Italy
ENERPAC Applied Power Italiana S.p.A.
Via Canova 4,
20094 Corsico (Milano)
Tel: +39 2 486 111 00
Fax: +39 2 486 012 88

Japan
Applied Power Japan Ltd.
10-17 Sasame Kita-Machi
Toda-Shi, Saitama #335, Japan
Tel: +81 048 421 2311
Fax: +81 048 421 8949

Malaysia
Applied Power Hytec (M) Sdn Bhd 22-1,
Jalan SS 15/8B
Subang Jaya, 47500
P.J. Selangor
West Malaysia
Tel: (0203) 73729 23/39/19
Fax: (0203) 737 29 18

Mexico
ENERPAC Applied Power Mexico S.A. de
C.V.
Avenida Principal,
La Paz #100
Fracc. Industrial La Paz
42084 Pachuca, Hidalgo
Tel: +52 771 337 00
Fax: +52 771 838 00

Singapore
Applied Power Asia Pte Ltd
47 Jalan Pemimpin,
#01-02 & 01-03
Sin Cheong Bldg
Singapore 577200
Thomson Road,
P.O. Box 114
Singapore 915704
Tel: +65 258 16 77
Fax: +65 258 28 47

South Korea
ENERPAC
Applied Power Korea Ltd.
163-12 Dodang-Dong, Choong-Ku,
Buchun-shi, Kyunggi-Do
Republic of Korea
Tel: +82 32 675 08 36
Fax: +82 32 675 30 02

Spain, Portugal
ENERPAC Applied Power International S.A.
A. Valgrande 14
Nave 12
28108 Alcobendas (Madrid), Spain
Tel: +34 91 661 11 25
Fax: +34 91 661 47 89

United Kingdom, Ireland
ENERPAC Limited
Unit 3 Colemeadow Road
North Moons Moat, Redditch
Worcester B98 9PB
United Kingdom
Tel: +44 01527 598 900
Fax: +44 01527 585 500

USA, Canada, Latin America and Caribbean
ENERPAC
6101 N. Baker Road
Milwaukee, WI 53209 USA
Tel: +1 414 781 66 00
Fax: +1 414 781 10 49

USA
User inquiries:
+1 800 433 2766
Distributor inquiries/orders:
+1 800 558 0530

Canada
User inquiries:
+1 800 426 4129
Distributor inquiries/orders:
+1 800 426 2284

Internet
www.enerpac.com

e-mail
info@enerpac.com

All Enerpac products are guaranteed against defects in workmanship and materials for as long as you own them.
Under this guarantee, free repair or replacement will be made to your satisfaction.

For your nearest authorized Enerpac Service Center, visit us at www.enerpac.com

Enerpac, a unit of  Tools and Supplies.