



TO PROTECT YOUR WARRANTY, USE ONLY ENERPAC HYDRAULIC OIL.

PARTS LIST

Item No.	Part No. VM-4/VM-40	Part No. VM-4L/VM-40L	No Req'd	Description
1	*F786.167	*F786.167	1	Gasket
2	A1006.245	A1006.245	1	Plug
3	A1007.245	A1007.245	1	Plug
4	CB303.038	CB303.038	1	Block, Adaptor
5	R515.245-2	R515.245-2	4	Plug
6	B1326.028	B1326.028	2	Capscrew, Socket Hd.
7	*B1111.803	*B1111.803	4	O-Ring
8	CH539.190	CH539.190	1	Body, Valve
9	*B1006.503	*B1006.503	3	O-Ring
10	*CF224.041	*CF224.041	3	Ring, Back-Up
11	CB25.041	CB25.041	3	Seal, Shear
12	*B1269.503	*B1269.503	1	O-Ring
13	*B1109.057	*B1109.057	1	Pin, Spring
14	CH542.950	CH542.950	1	Disc Assembly
15	CH536.104	CH536.104	1	Shaft
16	*B1007.503	*B1007.503	1	O-Ring
17	*A8049.562	*A8049.562	1	Ring, Back-Up
18	CB328.281	CB328.281	1	Bearing, Needle
19	CB327.101	CB327.101	1	Plate, Bearing
20	CB324.001	CB324.001	1	Bonnet
21	*A8039.110	*A8039.110	1	Spring
22	*B1006.016	*B1006.016	1	Ball
23	B1109.057	B1109.057	1	Pin, Spring
24	A8005.071	A8005.071	1	Disc, Detent
25	Y325.070	Y325.070	1	Handle
26	B1086.108	B1086.108	1	Washer
27	CB27.013	CB27.013	3	Guide, Spring
28	*CB28.110	*CB28.110	3	Spring
29	*B1003.503	*B1003.503	1	O-Ring
30	B1389.028	B1401.028	4	Capscrew (See Note 1)
31	A8076.048	A8076.048	1	Screw, Truss Hd.
32		Y123.900	1	Valve, Locking (See Note 2)
33		..CR356.013	2	Guide, Spring
34		*..B1116.803	2	O-Ring
35		..CJ656.110	2	Spring, Compression
36		*..B1008.016	2	Ball
37		*..B1011.503	2	O-Ring
38		*..B1113.564	2	Washer, Back-Up
39		*..Y126.290	2	Seat
40		*..B1009.503	1	O-Ring
41		*..B1111.564	2	Washer, Back-Up
42		..Y128.900	1	Piston Assy.
43		..CL888.950	1	Body Assembly
44		*..CR355.167	2	Gasket

*Indicates Items in Repair Kit VM-4K2.

*For Y123.900 Items, Order Repair Kit VL-4K.

NOTE 1: VM-40L uses (4) B1401.028 capscrews.

NOTE 2: Y123.900 (items 28 thru 40) are used on VM-4L (VM-40L only).

REPAIR AND SERVICE INSTRUCTIONS: For repair service and parts contact your nearest ENERPAC Authorized Technical Service Center. The ENERPAC Technical Service Center will provide complete and prompt service on all ENERPAC products. For the location of an ENERPAC Service Center, call Toll Free 1-800-433-2766. (In Wisconsin CALL 1-800-242-6636 — In Canada CALL 1-800-268-6975)

NOTE: This phone number is not for product repair information.

For service related information contact ENERPAC Service Department 1-414-781-6600

<p>PARTS AND SERVICE: For quality workmanship and genuine ENERPAC parts, select an Authorized ENERPAC Technical Service Center for your repair needs. Only repairs performed by an Authorized Service Center displaying the official ENERPAC sign are backed with full factory warranty. The Classified Section in Your Phone Book lists your nearest Service Center.</p>	<p>All ENERPAC tools are guaranteed from date of delivery to user against defects in workmanship and materials. Free repair or replacement will be made on all items not standing up to this guarantee. Following manufacturers trade customs, however, chains cannot be guaranteed. Warranty does not cover ordinary wear and tear, abuse or misuse, overloading, altered products or use of improper fluids. For prompt handling, send items requiring repairs prepaid, to your nearest ENERPAC authorized service center.</p>	<p>WARRANTY RETURN PROCEDURE: When question of warranty claim arises, the user should send his unit to the nearest ENERPAC Authorized Technical Service Center for inspection, transportation to be prepaid and evidence of purchase date furnished. If the claim comes under the terms of our warranty, the Authorized Technical Service Center will REPAIR OR REPLACE PARTS AFFECTED and return prepaid.</p>
--	--	---

