

UC3919-3DRW-BK/UC3919-3DRW-BL UC3919-3DRW-LG/UC3919-3DRW-OR UC3919-3DRW-RD

> -BK, -BL, -LG, -OR, -RD 3 DRAWER UTILITY CART

# **AWARNING**

#### SERVICE CART WEIGHT CAPACITY

| Maximum Total Net Load  |
|-------------------------|
| Top Compartment of Cart |
| Bottom Shelf of Cart    |
| 3-1/2" Drawers          |
| 4-1/2" Drawer           |

PLEASE NOTE: Loading cart beyond rated capacity may cause structural damage to the cart as well as personal and /or property damage. Please educate your customers to the dangers of overloading. Do not attempt to push cart with items on the top lid.

Read and understand all instructions. Failure to follow all instructions listed below, may result in electric shock, fire, explosion and/or serious personal injury. It is the responsibility of the owner to make sure all personnel read this manual prior to using the tool. It is also the responsibility of the tool owner to keep this manual intact and in a convenient location for all to see and read. If the manual or product labels are lost or not legible, contact Mac Tools for replacements. If the operator is not fluent in English, the product and safety instructions shall be read and discussed with the operator in the operator's native language by the purchaser/owner or his designee, making sure that the operator comprehends its contents.

# **▲WARNING**















Lock lid and drawers before moving.
Apply brake on locking casters anytime cart is in place.
Do not pull cart. Push from handle on end to move.
Units can tip or fall causing damage or personal injury.
Cart is designed to roll easily on flat surfaces and should not be used on uneven or inclined surfaces.
Do not open more than one loaded drawer at a time.
Do not stand on or step in drawers.
Keep children away from unit.
Wear gloves when lifting edges.
Failure to heed these warnings may result in personal injury and/or property damage.



**WARNING:** Cancer and Reproductive Harm. - www.P65Warnings.ca.gov.

# **ASSEMBLY INSTRUCTIONS**


# STEP 1: INSTALL CASTERS TO BOTTOM TRAY

(a) Install 4 casters to the bottom tray (#12). Two locking casters (#13) should be installed on either the right or left side, then the two non-locking casters (#17) should be installed on the opposite side, see drawing for reference.

(b) Fasten casters to tray with 16pcs bolts (#14/15/16), bolts are included.

TOOLS NEEDED: 14mm combination wrench

Fig 1.







UC3919-3DRW-BK/UC3919-3DRW-BL UC3919-3DRW-LG/UC3919-3DRW-OR UC3919-3DRW-RD

> -BK, -BL, -LG, -OR, -RD **3 DRAWER UTILITY CART**

# **ASSEMBLY INSTRUCTIONS**


# STEP 2: MOUNT PUSH HANDLE ONTO TUBE LEG

Install the Push Handle (#7) onto 2pc Tube Legs (#6) with 2pc Screws (#23)

Note: Plastic Cover (#24) comes factory installed on the push handle (#7).

TOOL NEEDED: 5mm Hex Key


# Fig 2.



# **ASSEMBLY INSTRUCTIONS**

#### STEP 3: MOUNT TUBE LEGS ONTO BOTTOM TRAY Fig 3.


- (a) Put left/right assembled legs (#6) on the bottom tray (#12)
- (b) Attach the legs (#6) to bottom tray (#12) using M6 Bolt/Nut (#22/21/20/19) TOOLS NEEDED: Screwdriver & 10mm combination wrench



# **ASSEMBLY INSTRUCTIONS**

# **STEP 4: MOUNT SUPPORT BEAM**

Fig 4. Mounting the Support Beam (#11) to cart body with M6 Screws (#18/19/20) TOOL NEEDED: Screwdriver



# **ASSEMBLY INSTRUCTIONS**

### **STEP 5: MOUNT CART BODY**

- (a) Turn over the assembled frame (Step 4)
- (b) Lift and move the cart body to the installing position Fig 5.
- (c) Fasten the Tube leg(#6) and the cart body with M6 x 25 bolts (#27/#20#19)
- (d) Fasten the Tube leg (#6) and support beams (#11) with M6 x 12 bolts (#22/#21/#20/#19)
- TOOLS NEEDED: 5mm Hex Key, 10mm combination wrench and Screwdriver




Fig 5.



# UC3919-3DRW-BK/UC3919-3DRW-BL UC3919-3DRW-LG/UC3919-3DRW-OR UC3919-3DRW-RD -BK, -BL, -LG, -OR, -RD 3 DRAWER UTILITY CART

# **TROUBLESHOOTING**

Problem: Drawers appear not to fit, do not slide in accurately and bump the cart sides.

**Solution:** The roller bearing slides must be fully engaged into the mounting slots on all drawers. They potentially could fall out of position in shipment or during assembly. Remove the drawer that is out of position. The drawer is removed by the two clips on the roller bearing slides.

Simply push the roller bearing slide back down into position.

Insert the drawer back onto the roller bearing slides.

# PARTS LIST AND PARTS DRAWING

| em No. | .Part No.        | No. | Req'd Description                       |  |
|--------|------------------|-----|---|--|
| 1      | MB303LIDR        | 1   | Lid - Red                               | 26 RS303LMR 1 Lock Mechanism - Red                                     |
|        | MB303LIDBK       | 1   | Lid - Black                             | RS303LMBK 1 Lock Mechanism - Black                                     |
|        | MB303LIDBL       | 1   | Lid - Blue                              | RS303LMBL 1 Lock Mechanism - Blue                                      |
|        | MB303LID0R       | 1   | Lid - Orange                            | RS303LMOR 1 Lock Mechanism - Orange                                    |
|        | MB303LIDLG       | 1   | Lid - Lime Green                        | RS303LMLG 1 Lock Mechanism - Lime Green                                |
| 2      | RS303LKBK        | 1   | Lock Kit - Black                        | 27 ** 4 M6x25 Inner hexagon head screw - Black                         |
| 3      | RS303GPBK        | 2   | Gas Piston - Black                      | not shown RS303LMLK 1 Product Label Kit                                |
| 4      | RS303DPTBK       | 3   | Drawer Pull - Textured Black            | Also available:  |
| 5      |                  | 1   | Cart body                               | * RS89UCCBBK – Caster Hardware Kit (incl #14. 15 & 16) - Black         |
| 6      | RS303TLTBK       | 1   | Tube Leg - Textured Black (4 pc set)    | ** RS303HK1 – Leg & Frame Hardware Kit (incl #18, 19, 20, 21, 22 & 27) |
| 7      | RS303PHTBK       | 2   | Push Handle - Textured Black (incl #24) | 11330311K1 - Leg & Frame Hardware Kit (111C1 #10, 13, 20, 21, 22 & 21) |
| 8      | MB3033D          | 1   | 3-1/2" Drawer - Red                     |  |
|        | MB3033DBK        | 1   | 3-1/2" Drawer - Black                   |  |
|        | MB3033DBL        | 1   | 3-1/2" Drawer - Blue                    | 1  |
|        | MB3033D0R        | 1   | 3-1/2" Drawer - Orange                  | $\frac{1}{2}$  |
|        | MB3033DLG        | 1   | 3-1/2" Drawer - Lime Green              |  |
| 9      | MB3035D          | 2   | 4-1/2" Drawer - Red                     |  |
|        | MB3035DBK        | 2   | 4-1/2" Drawer - Black                   |  |
|        | MB3035DBL        | 2   | 4-1/2" Drawer - Blue                    |  |
|        | MB3035DOR        | 2   | 4-1/2" Drawer - Orange                  |  |
|        | MB3035DLG        | 2   | 4-1/2" Drawer - Lime Green              | TOOLS / 1 / 5  |
| 10     | RSRBSLIDEC2      | 3   | Roller Bearing Slides                   |  |
| 11     | RS303SBR         | 2   | Support Beam - Red                      | 25   |
|        | RS303SBBK        | 2   | Support Beam - Black                    | A A A A A A A A A A A A A A A A A A A                                  |
|        | RS303SBBL        | 2   | Support Beam - Blue                     | 24   |
|        | RS303SBOR        | 2   | Support Beam - Orange                   |  |
|        | RS303SBLG        | 2   | Support Beam - Lime Green               | 23/   \\   |
| 12     | RS303BTR         | 1   | Bottom Tray - Red                       |  |
| 12     | RS303BTBK        | 1   | Bottom Tray - Black                     |  |
|        | RS303BTBL        | 1   | Bottom Tray - Blue                      | 22   |
|        | RS303BTOR        | 1   | Bottom Tray - Orange                    |  |
|        | RS303BTLG        | 1   | Bottom Tray - Lime Green                |  |
| 13     | RS323UCLC        | 2   | 5"x1.5" Swivel Locking Caster           |  |
| 14     | *                | 16  | Hex Screw (M8x16)                       |  |
| 15     | *                | 16  | Spring Spacer (8.5x1.5)                 |  |
| 16     | *                | 16  | Spacer (8.5x1.5)                        |  |
| 17     | RS323UCNLC       | 2   | 5x1.5" Swivel Non-locking Caster        |  |
| 17     | #8323UUNLU<br>** | 4   | •                                       |  |
|        | **               |     | M6x12 Inner hexagon head screw - Black  | 20   |
| 19     | **               | 16  | 8 Spacer - Black                        | 19   |
| 20     | **               | 16  | 8 Spring Spacer - Black                 |  |
| 21     | **               | 8   | M6 Nut - Black                          |  |
| 22     |                  | 8   | M6x45 Round Head Bolts - Black          |  |
| 23     | RS303HK2         | 4   | Push Handle Hardware Kit (M6x50) Screws | - Plack  |
| 24     | RS303PHC         | 4   | Push handle Cover (incl w/#7)           | 16   |
| 25     | RS3035ELK        | 1   | EVA Liner Kits (5 pc set)               |  |
|        |                  |     |   | 15   |