

- Wide angle beam maximizes light over a specific work area.
- Pivoting head rotates 300° horizontally and 180° vertically.
- Spare bulb inside lens cover for easy replacement.
- Lightweight, compact design makes this light durable and easily portable.

OPERATING INSTRUCTIONS

Fully charge the battery pack before use. To remove the battery pack from the flashlight, press the button on the sides of the battery pack. Slide the battery forward to separate the battery from the flashlight. After charging, insert the battery pack into the flashlight all the way until it locks in place with a little click. (See Figure 1).

RUN TIME:

A fully charged flashlight can run about 3.5 hours.

HEAD ANGLE:

Pivoting head rotates 300° horizontally and 180° vertically, which allows the light to be projected in any direction. Adjust as desired.

REPLACING LIGHT BULB:

⚠ WARNING The bulb is very hot after operation. Wait until bulb cools down before attempting to replace it.

⚠ WARNING Always remove the battery pack from handle before changing the bulb.

1. Rotate lens cap counterclockwise (see Figure 2) and remove.
2. Remove bulb from housing.
3. Reinstall replacement bulb in housing.
4. Reinstall lens cap and rotate clockwise to tighten.

Note: One replacement bulb is provided, located inside lens cover. Future replacement bulbs (7.2 volt, .75 amp) are readily available at most hardware stores.




Figure 1

Note:
Battery and
charger are
NOT included.




Figure 2