





**REPLACEMENT
PARTS**

**MODEL NO.
72701A**

**CAPACITY
1 TON**

**DESCRIPTION
UNDERHOIST AIR/HYD. TRUCK TRANSMISSION JACK**

norco®

INDEX NO.	DESCRIPTION	PART NUMBER	REQ'D NO.
1	"L" Bracket	229385	4
2	Saddle Plate Assembly	229386	1
3	Lock Screws	229357	4
4	Bolt	229387	1
5	Washer	229388	1
6	Nut	229389	1
7	Chain & Hook Assembly	229390	1
8	Adapter	229759	1
9	Hydraulic Block Assembly	282705	1
10	Anchor Trunion	229363	1
11	Saddle Base	229364	1
12	Saddle Tilt Pin	229365	1
13	Trunion	229369	1
14	Side Tilt Pin	229370	1
15	Trunion	229371	1
16	Threaded Trunion	229372	1
17	Tilt Screw	229366	2
18	Adapter	229391	1
19	Tilt Screw Knob	229367	2
20	Guide Ram	282711	1
21	Collar	229373	2
22	Bearing	229374	4
23	Retainer	229377	4
24	Retainer	229378	2
25	Retainer	229379	2
26	Retainer	229380	4
27	Set Screw	229381	4
28	Expansion Pin	229368	2
29	Bolt	229382	1
30	Nut	229383	1
31	Collar	229384	2
32	Split Retaining Ring	282712	1
33	Caster	229713	4
34	Caster Bolt	229714	16
35	Guide Ring	282713	1

INDEX NO.	DESCRIPTION	PART NUMBER	REQ'D NO.
36	Ram Retainer Nut	282714	1
37	Ram Retainer Nut	282716	1
38	Mounting Screw	229719	8
39	Mounting Washer	229721	8
40	Caster Washer	229722	8
41	Caster Nut	229723	8
42	Back Pad	282717	1
43	Side Pad	282718	2
44	Bottom Pad	282719	1
45	Screw	282721	2
46	Washer	282722	2
47	Retainer Block	282723	2
48	Split Retaining Ring	282724	1
*49	O-Ring	282726	1
50	Ram Bearing	282727	1
*51	O-Ring	282728	1
*52	Backup Ring	282729	1
*53	Ram Seal	282731	1
54	Retaining Ring	282732	1
55	Pipe Extension	282733	1
56	Pipe Elbow	282734	1
57	Hose	282736	1
58	45° Fitting	282737	1
59	Hose Guard	282738	1
60	Air/Hydraulic Foot Pump	910130A	1
61	Bolt	282702	2
62	Bronze Bushing	282709	1
63	Nut	282704	2
64	Complete Saddle Assembly	229755	1
*65	Wiper Ring	282706	1
66	Cylinder Nut	282707	1
67	Jack Base Assembly	282715	1

*Items included in Repair Kit 282725

REPLACEMENT
PARTS

MODEL NO.
72701A

CAPACITY
1 TON

DESCRIPTION
UNDERHOIST AIR/HYD. TRUCK TRANSMISSION JACK

