




**REPLACEMENT
PARTS**

**MODEL NO.
86002A**

**CAPACITY
6000 LBS.**

**DESCRIPTION
SCISSOR LIFT**

norco®

PART NO.	DESCRIPTION	PART. NO.	QTY.	PART NO.	DESCRIPTION	PART. NO.	QTY.
1	Reservoir with Cap for 86002A	45100449	1	29	Connecting Pin for 86002A	45100325	2
2	Table for 86002A	45100308	1	30	Cylinder Pin for 86002A	45100326	2
3	Retaining Ring (18) for 86002A	45100309	6	31	Cylinder Assembly Left for 86002A	45100054	1
4	Locking Nut (M20) for 86002A	45100310	1	32	Cylinder Assembly 35B Right for 86002A	45100055	1
5	Oil Pipe Cylinder Connector for 86002A	45100311	3	33	Safety Lock Assy. for 86002A	45100327	1
6	Branch Inlet Pipe for 86002A	45100312	2	34	Cylinder Assy. Retaining Ring for 86002A	45100430	2
7	Oil Pipe Connector for 86002A	45100311	1	35	Saddle Holder for 86002A	45100059	4
8	Power Unit for 86002A	45100095	1	36	Rubber Saddle for 86002A	45100060	4
9	Nut (M8) for 86002A	45100313	4	37	Plate Lock Nut for 86002A	45100433	4
10	Washer (8) for 86002A	45100314	4	38	Plate Washer for 86002A	45100434	4
11	Brake Steel Cable for 86002A	45100057	1	39	Plate for 86002A	45100061	4
12	Hex Screw (M8) for 86002A	45100307	4	40	Bolt for 86002A	45100062	4
13	Brake Lever Assembly for 86002A	45100058	1	41	Ring for 86002A	45100329	2
14	Bolt (M8) for 86002A	45100096	4	42	Dolly Wheel for 86002A	45100330	2
15	Dolly for 86002A	45100316	1	43	Dolly Wheel Nut for 86002A	45100455	2
16	Rubber Cap for 86002A	45100306	3	44	Safety Lock Assy. Pin for 86002A	45100063	1
17	Hyd. Pump Oil Pipe Connector for 86002A	45100347	1	45	Safety Lock Assy. Spring for 86002A	45100064	1
18	General Inlet Pipe for 86002A	45100056	1	46	Safety Lock Assy Lock Block for 86002A	45100065	1
19	Check Valve for 86002A	45100317	2	47	Safety Lock Assy. Pole for 86002A	45100066	1
20	Safety Lock Pin for 86002A	45100318	1	48	Safety Lock Assy. Lock Wheel for 86002A	45100067	1
21	Cylinder Assy. Retaining Ring for 86002A	45100429	6	49	Safety Lock Assy. Nut for 86002A	45100068	1
22	Scissor Pin for 86002A	45100319	2	50	Safety Lock Assy. Bolt for 86002A	45100069	1
23	Outer Scissor for 86002A	45100320	1	51	Safety Lock Sheath for 86002A	45100071	1
24	Inner Scissor for 86002A	45100321	1	52	Check Valve Washer for 86002A	45100315	1
25	Wheel Pin for 86002A	45100322	2	53	Check Valve Bolt for 86002A	45100447	1
26	Large Wheel for 86002A	45100323	2	54	Scissor Lock Assy. Cylinder Pin for 86002A	45100446	2
27	Small Wheel for 86002A	45100324	2	55	Cylinder Assembly Pin for 86002A	45100458	2
28	Scissor Wheel Pin for 86002A	45100432	2	56	Pump and Cart Assy. for 86002A	45100102	1