




INDEX NO.	DESCRIPTION	PART NO.	QTY.
1	Jack Base	N/A	1
2	Set Screw	612183	2
3	Check Ball		
4	Fitting		
5	Spring	612176	1
6	Washer	612179	1
7	Set Screw	612178	1
8	Spring	612213	2
9	3/16" Check Ball	9007	3
10	5/16" Check Ball	9005	1
11	Release Valve	612181	1
12	Washer	612217	1
13	Pump Housing	612219	1
14	O-Ring	612223	1
15	Backup Ring	612224	1
16	Pump Piston	612221	1
17	Steel Hose	612212	1
18	90° 1/8" Elbow	612211	2
19	Washer	612186	1
20	Air Motor w/Air Valve Assy.	612210	1
21	Washer	612224	1
22	O-Ring	612222	2
23	Reservoir	612190	1
24	O-Ring	612189	1
25	Fill Plug	612188	1
26	Primary Cylinder	612203	1
27	C-Ring	612202	1
28	Ram Bearing	612201	1
29	Backup Ring	612198	1
30	O-Ring	612199	1
31	Washer	612197	1
32	Spring	612196	1
33	Fitting	612194	1
34	7/32" Check Ball	9001	2
35	Pin	612193	1
36	Ram Bearing	612187	1
37	Pin	612192	1
38	Ram	612191	1
39	Ram Steel Washer	612214	1
40	Primary Cylinder Nut	612207	1
41	O-Ring	612206	1
42	Extension Screw w/Bushing	612205	1
43	Handle Assembly	45100942	1
46	Lever Link Assembly	612182	1
47	Air Valve	220140	1
48	Air Hose	220150	1
49	Set Screw	162184	1

05/27/26

**REPLACEMENT
PARTS**

**MODEL NO.
76312B**

**CAPACITY
12 TON**

**DESCRIPTION
AIR OPERATED HYDRAULIC BOTTLE JACK**

norco®