




INDEX NO.	DESCRIPTION	PART NO.	QTY.
1	Jack Base	620120	1
2	Set Screw	612183	4
3	Check Ball	9001	1
4	Fitting		1
5	Spring	612176	1
6	O-Ring	612177	2
7	Set Screw	620121	1
8	Spring	612213	2
9	Check Ball	9007	4
10	Check Ball	9005	1
11	Release Valve	612181	1
12	Washer	612217	1
13	Pump Housing	612219	1
14	O-Ring	612223	1
15	Backup Ring	612224	1
16	Plunger	612221	1
17	Steel Hose	620138	1
18	90° Elbow	612211	2
19	Washer	612186	1
20	Air Pump	620137	1
21	Washer Cylinder to Base	620132	1
22	O-Ring	620166	2
23	Reservoir	620160	1
24	O-Ring	612189	1
25	Fill Plug	612188	1
26	O-Ring	620140	1
27	Primary Cylinder	620164	1
28	C-Ring	620163	1
29	Ram Bearing	620126	1
30	O-Ring	620162	1
31	Backup Ring	620167	1
32	O-Ring	620162	1
33	Backup Ring	620167	1
34	Washer	612197	1
35	Spring	612196	1
36	Fitting	612194	1
37	Check Ball	9001	1
38	Pin	620125	1
39	Pin	620124	1
40	Ram	620161	1
41	Ram Steel Washer	620132	1
42	Primary Cylinder Nut	620136	1
43	O-Ring	620135	1
44	Dust Seal	620134	1
45	Extension Screw w/Bushing	620185	1
46	Handle Assembly	45100942	1
48	Pump and Linkage Assembly	612182	1

*Items in Repair Kit 612200

07/23/26

**REPLACEMENT
PARTS**

**MODEL NO.
76720B**

**CAPACITY
12 TON**

**DESCRIPTION
AIR OPERATED HYDRAULIC BOTTLE JACK**

norco®