



SPARE PARTS LIST 1100-lb Transmission Jack

Model # 41100

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1*	511-7-0250-207	O-ring	1	41	410-4-4010-203	Bearing	4
2	275-6-1801-206	Top nut	1	42	410-3-5100-405	Rear caster	4
3*	511-7-0568-208	O-ring	1	43	605-3-0120-007	Lock washer	2
4	450-6-1201-108	Piston rod assy.	1	44	667-5-0160-003	Retaining ring "C"	5
5	275-6-1209-107	Ram bearing	1	45	450-3-5600-205	Saddle holder	1
6*	577-7-0310-016	Back-up ring	1	46	450-6-5019-109	Pin	1
7*	521-7-0310-115	U-cup		47	450-6-4405-109	Pin saddle holder	1
8	450-6-1801-205	Cylinder	1	48	450-6-5006-100	Pin	1
9	450-6-1803-106	Reservoir	1	49	651-2-0127-016	Nut	1
10*	505-9-0092-207	Filler plug	1	50	450-3-5700-108	Screw assy.	1
11*	513-3-0580-006	Washer	1	51	450-6-5007-102	Screw (up & down)	1
12*	511-7-0560-101	O-ring	1	52	653-1-0095-301	Bolt	2
13*	577-7-0365-103	Back-up ring	1	53	450-3-5010-10308	Saddle assy.	1
14*	511-7-0332-108	O-ring	1	54	450-4-5300-108	Angle bar	2
15*	322-6-1809-200	Seal cylinder	1	55	450-3-5100-104	Toe I	2
16	601-7-0006-005	Steel ball	2	56	450-3-5200-108	Toe II	2
17	450-6-1601-104	Base	1	57	681-2-0095-013	Wing nut (lager)	4
18*	551-7-0100-008	Oil seal	1	58	681-2-0063-010	Wing nut (small)	2
19	450-4-1700-104	Release valve assy.	1	59	450-6-5201-108	Joint	2
20	601-7-0008-009	Steel ball	1	60	451-6-6200-108	Chain	1
21*	515-3-0090-021	Washer	1	61	651-2-0095-019	Nut	4
22	450-6-1409-102	Bearing	1	62	605-3-0095-307	Lock washer	4
23	451-6-1302-101	Handle sleeve seat	1	63	602-4-0030-029	Cotter pin	1
24	450-6-1401-106	Pump cylinder	1	64	450-6-4312-203	Parallel link	2
25*	324-4-1310-106	Seal assy.	1	65	450-3-4100-109	Lift arm assy.	1
26*	511-7-0090-403	O-ring	1	66	450-1-1000-108	Hydraulic unit	1
27	450-6-1306-102	Pump piston	1	67	611-3-0130-101	Washer	4
28	566-4-0080-306	Pin	1	68	649-1-0079-105	Bolt	2
29	566-4-0100-407	Pin	1	69	661-2-0079-101	Nut	2
30	513-5-0016-018	Retaining ring	2	70	G52-3-9903-104	Handle Assembly	-
31	324-6-1301-400	Handle sleeve	1	(*)	450-3-9901-108	Repair kit	-
32	532-8-0040-012	Filter	1				
33	347-3-2101-103	Handle	1				
34	506-9-0215-011	Handle grip	1				
35	450-6-4409-107	Hyd. unit pivot pin	2				
36	677-5-0120-009	Snap ring "E"	2				
37	450-3-3000-100	Frame assy.	1				
38	450-6-4115-100	Main pivot pin	1				
39	667-5-0220-005	Retaining ring "C"	6				
40	661-2-0120-010	Nut	6				

* Repair Kit includes 1, 3, 6, 7, 10, 11, 12, 13, 14, 15, 18, 21, 25, 26.



SPARE PARTS LIST 1100-lb Transmission Jack

Model # 41100


ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	*	O-ring	1	41	410-4-4010-203	Bearing	4
2	N/A	Top nut	1	42	410-3-5100-405	Rear caster	4
3	*	O-ring	1	43	N/A	Lock washer	2
4	N/A	Piston rod assy.	1	44	N/A	Retaining ring "C"	5
5	N/A	Ram bearing	1	45	450-3-5600-205	Saddle holder	1
6	*	Back-up ring	1	46	450-6-5019-109	Pin	1
7	*	U-cup	1	47	450-6-4405-109	Pin saddle holder	1
8	N/A	Cylinder	1	48	450-6-5006-100	Pin	1
9	N/A	Reservoir	1	49	N/A	Nut	1
10	*	Filler plug	1	50	450-3-5700-108	Screw assy.	1
11	*	Washer	1	51	N/A	Screw (up & down)	1
12	*	O-ring	1	52	N/A	Bolt	2
13	*	Back-up ring	1	53	450-3-5010-10308	Saddle assy.	1
14	*	O-ring	1	54	450-4-5300-108	Angle bar	2
15	*	Seal cylinder	1	55	450-3-5100-104	Toe I	2
16	N/A	Steel ball	2	56	450-3-5200-108	Toe II	2
17	N/A	Base	1	57	681-2-0095-013	Wing nut (lager)	4
18	*	Oil seal	1	58	681-2-0063-010	Wing nut (small)	2
19	450-4-1700-104	Release valve assy.	1	59	450-6-5201-108	Joint	2
20	N/A	Steel ball	1	60	451-6-6200-108	Chain	1
21	*	Washer	1	61	N/A	Nut	4
22	N/A	Bearing	1	62	N/A	Lock washer	4
23	N/A	Handle sleeve seat	1	63	N/A	Cotter pin	1
24	N/A	Pump cylinder	1	64	450-6-4312-203	Parallel link	2
25	*	Seal assy.	1	65	450-3-4100-109	Lift arm assy.	1
26	*	O-ring	1	66	450-1-1000-108	Hydraulic unit	1
27	N/A	Pump piston	1	67	N/A	Washer	4
28	N/A	Pin	1	68	N/A	Bolt	2
29	N/A	Pin	1	69	N/A	Nut	2
30	N/A	Retaining ring	2	70	G52-3-9903-104	Handle Assembly	-
31	324-6-1301-400	Handle sleeve	1	(*)	450-3-9901-108	Repair kit	-
32	N/A	Filter	1				
33	N/A	Handle	1				
34	506-9-0215-011	Handle grip	1				
35	450-6-4409-107	Hyd. unit pivot pin	2				
36	N/A	Snap ring "E"	2				
37	N/A	Frame assy.	1				
38	450-6-4115-100	Main pivot pin	1				
39	N/A	Retaining ring "C"	6				
40	N/A	Nut	6				

* Repair Kit includes 1, 3, 6, 7, 10, 11, 12, 13, 14, 15, 18, 21, 25, 26.



1100-lb Transmission Jack

Model # 41100



Exploded Drawing
3rd Edition © Oct. 2005