

WALKER SERVICE DIVISION

CAPACITY 1% TON AIR-OPERATED ONE-END LIFT

JACK PARTS MANUAL MODEL J-96

SERIES "C"





Code	Part	Description	No.
No.	No.		Required
1	223963	Air Valve Equalizing Hose Elbow Grease Fitting Nut	1
2	223965		1
3	223964		2
4	G16711		4
5	207169		1
6 7 8 9	223962 223967 223575 223960 223619	Spring Shaft "U" Cup Piston Pin	1 2 2 2 2 2 2 2
11 12 13 14 15	220018 223968 221788 204465 209970	Retaining Ring Shaft Washer Cotter Pin Lockwasher	2 1 4 4 8 8
16	212688	Screw Cotter Pin Shaft L.H. Side Frame Assy. Front Wheel	8
17	204582		2
18	223968		1
19	223982		1
20	221715		2
21 22 23 24 25	204324 224006 223980 223981 223970	Washer Adapter Assy. Front Axle R.H. Side Frame Assy. Lift Assy.	4 1 1 1 1 1 1 1
26	224002	Ram & Sleeve Assy.	2
27	223999	Safety Dog Handle	1
28	223961	Safety Dog	2
29	204426	Cotter Pin	4
30	224011	Safety Dog Pin	1
31 32	223959 223991	Cylinder Cap Cylinder & Sleeve Assy. (Two cylinders in one welded Assy.)	2

WALKER SERVICE

We have Factory-owned BRANCHES AND AUTHORIZED SERVICE DEPOTS located in the principal cities of the United States and Canada. They are operated by FACTORY TRAINED STAFFS and carry a comprehensive stock of REPAIR PARTS. Before returning Jacks for service, please contact the Factory or your Walker DISTRIBUTOR for location of Branch or Service Depot nearest you.


WALKER MANUFACTURING COMPANY GENERAL OFFICE: RACINE, WISCONSIN FACTORY SERVICE BRANCHES: - ATLANTA, GEORGIA - CLEVELAND, OHIO - KANSAS CITY, MISSOURI -PHILADELPHIA, PENNA. WALKER BRANCHES ARE LISTED

WALKER SERVICE DIVISION

CAPACITY 1% TON AIR-OPERATED ONE-END LIFT JACK PARTS MANUAL MODEL J-96 SERIES "C"

Code	Part	Description	No.
No.	No.		Required
1	223963	Air Valve Equalizing Hose Elbow Grease Fitting Release Knob	1
2	223965		1
3	223964		2
4	G16711		4
5	225999		1
7 8 9 10 11	223967 223575 223960 223619 220018	Shaft "U" Cup Piston Pin Retaining Ring	2 2 2 2 2 2
12	223969	Rear Wheel	2
13	221788	Washer	4
14	204465	Cotter Pin	4
15	209970	Lockwasher	8
16	212688	Screw	8
17	204582	Cotter Pin	2
18	223968	Shaft	1
19	223982	L.H. Side Frame Assy.	1
20	221715	Front Wheel	2
21	204324	Washer	4
22 23 24 25 26 27	226006 223980 223981 223970 225852 225850	Adapter Assy. Front Axle R.H. Side Frame Assy. Lift Assy. Ram & Sleeve Assy. Safety Dog Handle	1 1 1 1 2
28 29 30 31 32	225849 204426 224011 225649 223991	Safety Dog Cotter Pin Safety Dog Pin Cylinder Cap Cylinder & Sleeve Assy. (Two cylinders in one welded Assy.)	2 4 1 2

Order By Part Number, Not Code Number



WALKER SERVICE

We have Factory-owned BRANCHES AND AUTHORIZED SERVICE DEPOTS located in the principal cities of the United States and Canada. They are operated by FACTORY TRAINED STAFFS and carry a comprehensive stock of REPAIR PARTS. Before returning Jacks for service, please contact the Factory or your Walker DISTRIBUTOR for location of Branch or Service Depot nearest you.

WALKER MANUFACTURING COMPANY GENERAL OFFICE: RACINE, WISCONSIN FACTORY SERVICE BRANCHES: - ATLANTA, GEORGIA - CLEVELAND, OHIO - KANSAS CITY, MISSOURI - PHILADELPHIA, PENNA. WALKER BRANCHES ARE LISTED -