



ZINKO HYDRAULIC JACKS

Repair parts list for Transmission Jack - ZM Model

Effective: Nov. 01, 98

Model: ZM-800

Part #	Description
9150008- 1	Master Cylinder Body
9150008- 2	Bracket
9150008- 3	Plug
9150008- 3-0	Plug O Ring
9150008- 4	Pump Piston
9150008- 4-0	Pump O-Ring
9150008- 5	Pump Linkage Bar
9150008- 6	Release Valve
9150008- 7	Oil block screw
9150008- 8	Oil Tank
9150008- 9	Oil Plug
9150008- 10	Pump Pin
9150008- 11	Handle
9150008- 12	Cylinder
9150008- 13	Piston
9150008- 14	Rod
9150008- 15	Cylinder Packing
9150008- 16	Cylinder Nut
9150008- 16-0	O-Ring
9150008- 17	Copper Collar

Part #	Description
9150008- 18	Ram (Rod fixing pipe)
9150008- 19	Frame Ass'y
9150008- 20	Elevator Arm Ass'y
9150008- 21	Guide Arm
9150008- 22	Elevator Arm
9150008- 23	Saddle Base support
9150008- 24	Flat Plate
9150008- 25	Angle Tilt Screw
9150008- 26	Chain
9150008- 27	Saddle Angle
9150008- 28	Hook
9150008- 29	Adjust Knob
9150008- 30	Angle Plate
9150008- 31	Cylinder Pin
9150008- 32	Arm Pin
9150008- 33	Wheel Ass'y
9150008- 37	Rod fixing bolt
9150008- SK	Repair kits
9150012- SK	Repair kits
9150018- SK	Repair kits

M-800 MISSION JACK

